


# ACS SASSI Application to Linear and Nonlinear Seismic SSI Analysis of Nuclear Structures Subjected to Coherent and Incoherent Inputs

## 1-Day Training Notes




Ghiocel Predictive Technologies Inc.

**Dr. Dan M. Ghiocel**

Email: [dan.ghiocel@ghiocel-tech.com](mailto:dan.ghiocel@ghiocel-tech.com)

Ghiocel Predictive Technologies Inc.

<http://www.ghiocel-tech.com>



**“Dan Ghiocel” International Research Center**

**UTCB, Bucharest, Romania**

**February 27, 2013**

# **Introduction to ACS SASSI Software Capabilities**

**SSI Modeling and Algorithms**

**Modular Configuration**

**Description of GUI and SSI Software Modules**

**SSI Analysis Runs, Restart and Post-Processing**


**Special Reporting on SSI Substructuring Methods**

**ACS SASSI-ANSYS Integration (New, Option A)**

# Seismic SSI Analysis Problem

Seismic SSI Analysis Aspects:

- Wave Propagation/Scattering
- Structural and Soil Modeling



# SSI Analysis Complex Frequency Approach

The equation of motion of the SSI system is:

$$[M]\{\ddot{u}\} + [C]\{\dot{u}\} + [K]\{u\} = -\{m\}\ddot{y}$$

$$[M]\{\ddot{u}\} + [K^*]\{u\} = -\{m\}\ddot{y}$$

Assume:  $\ddot{y} = \ddot{Y}e^{i\omega t}$

Then:  $\{u\} = \{U\}e^{i\omega t}$

$$([K^*] - \omega^2 [M])\{U\} = -\{m\}\ddot{Y}$$

Solve for complex transfer functions for each frequency:

$$([K^*] - \omega_s^2 [M])\{A_s\} = -\{m\}$$

Then the solution in frequency domain:

$$\{U_s\} = \{A_s\}\ddot{Y}$$

Use Fourier Transform for transient time histories, and the compute solution in time domain:

$$u_j(t) = \text{Re} \sum_{s=0}^{N/2} U_{j,s} e^{i\omega_s t}$$


# Linear Soil-Structure Interaction Analysis

## Computational Steps for Linear SSI Solution:

Soil structure interaction problem subjected to the seismic excitation is solved in the frequency domain following steps:

1. Solve the site response problem
2. Solve the impedance problem
3. Form the load vector
4. Form the complex stiffness matrix
5. Solve the system of linear equations of motion

# Incoherent SSI Analysis in ACS SASSI



**Motion Incoherency affects free-field motion at interaction nodes**

**Flexible Volume Method** (using all excavated volume nodes)

$$\begin{bmatrix}
 C_{ii}^s - C_{ii}^e + X_{ii} & -C_{iw}^e - X_{iw} & C_{is}^s \\
 -C_{wi}^e + X_{wi} & -C_{ww}^e + X_{ww} & \mathbf{0} \\
 C_{ci}^s & \mathbf{0} & C_{cs}^s
 \end{bmatrix}
 \begin{Bmatrix}
 U_i \\
 U_w \\
 U_c
 \end{Bmatrix}
 =
 \begin{Bmatrix}
 X_{ii} U_i' + X_{iw} U_w' \\
 X_{wi} U_i' + X_{ww} U_w' \\
 \mathbf{0}
 \end{Bmatrix}$$

**Flexible Interface Methods** (using excavation volume outer surface nodes)

$$\begin{bmatrix}
 C_{ii}^e - C_{ii}^e + X_{ii} & -C_{iw}^e & C_{is}^s \\
 -C_{wi}^e & -C_{ww}^e & \mathbf{0} \\
 C_{si}^s & \mathbf{0} & C_{ss}^s
 \end{bmatrix}
 \begin{Bmatrix}
 U_i \\
 U_w \\
 U_s
 \end{Bmatrix}
 =
 \begin{Bmatrix}
 X_{ii} U_i' \\
 \mathbf{0} \\
 \mathbf{0}
 \end{Bmatrix}$$

$\mathbf{C}(\omega)\mathbf{U}(\omega) = \mathbf{Q}(\omega)$   
 where  $\mathbf{C}(\omega) = \mathbf{K} - \omega^2\mathbf{M}$

# Seismic Site Response

- The original site is assumed to consist of horizontal soil layers overlying a halfspace.
- All material properties are assumed to be visco-elastic materials.
- Solutions for inclined body waves and surface waves
- Only the free-field displacements of the layer interfaces where the structure is connected are of interest. For the vertically propagating wave types, displacement amplitudes are:

$$\mathbf{u}'_f(x) = \mathbf{U}'_f \exp[i(\omega t - kx)]$$

- Effective discrete methods are used for determining appropriate mode shapes and wave numbers corresponding to control motions at any layer interface for inclined P-, SV-, and SH- waves, Rayleigh waves and Love waves.
- Soil hysteretic behavior is idealized using the Seed-Idriss Equivalent Linear Model

# Soil Layer Sizes (It impacts on SSI model)

- For such elements the accuracy of the solution is function of the method used to compute the mass matrix and an accuracy better than 10 percent on wave amplitude is obtained if the element size  $h$  follows the relations shown below:

$$h \leq \begin{cases} 1/8 \lambda_s & \text{for lumped mass matrix} \\ 1/5 \lambda_s & \text{for consistent mass matrix} \\ \boxed{1/5 \lambda_s} & \text{for mixed mass matrix} \end{cases} \leftarrow$$

- The wave length is obtained from

$$\lambda_s = \frac{V_s}{f_{\max}}$$



# Site Response Model for Body Waves

## Incident Plane SV and P Waves

The equation of motion to the soil system subjected to inclined P- and/or SV- waves:


$$([A]k^2 + i[B]k + [G] - \omega^2 [M])\{U\} = \begin{Bmatrix} 0 \\ P_b \end{Bmatrix}$$

Solution to the above equation yields the displacement vector  $\{U\}$ .

For vertically propagating waves it reduces to much simpler equation (Chen, 1980). The free-field motion at any distance  $x$  can be obtained from the solution using the relation

$$\{U(x)\} = \{U\} \exp(-ikx) \delta$$

### Incident Plane SV Waves



# Modeling of Semi-Infinite Halfspace Baserock


## The Variable Depth Method

The total depth  $H$  of the added layers varies with frequency and is set to:




$$H = 1.5 \frac{V_s}{f}$$

The total thickness of the  $n$  layers is:




$$H = h_0 + \alpha^2 h_0 + \dots + \alpha^n h_0 = \frac{(\alpha^n - 1)h_0}{\alpha - 1}$$



Baserock




## Vertically Loaded Halfspace



## Horizontally loaded Halfspace

# 3D Transmitting Boundary Matrices

The 3D Transmitting Boundary Matrix Uses An Axisymmetric Model (Kausel, 1976):



Degrees of Freedom on Axisymmetric Transmitting Boundary

# 3D Transmitting Boundary Matrices


- Generalized Rayleigh and Love waves eigen-solutions and Fourier expansion are used to compute the force-displacement relationship for site response:

$$\{P\}_m = [R]_m \{U\}_m$$

$$[R]_m = r_0 \left\{ [A][\psi]_m [K^2] + ([D] - [E] + m[N][\phi]_m [K] - m \left( \frac{m+1}{2} [L] + [Q] \right) [\psi]_m [W(r_0)]^{-1} \right\}$$

# Compute Flexibility Matrix

For each node dof the flexibility is computed using an axisymmetric model that includes a central zone with radius of cylindrical elements enclosed by an axisymmetric transmitting boundary.



Explanation  
★ Interaction Node

# Impedance Analysis

Computational Steps:

1. Compute Flexibility Matrix
2. Compute Impedance Matrix using
  - Flexible Volume Method (uses all the interaction nodes)
  - Skin Method (more approximate, not V&V)
  - Flexible Interface Method (used just the excavated interface nodes)
3. Equivalent Global Impedances (Optional)

# Flexible Volume/Interface Method

In this method, the flexibility matrix need be computed for all the interacting nodes using the methods described above.

The impedance matrix is obtained by inverting the flexibility matrix, i.e.,

$$\mathbf{X}_{ff} = \mathbf{F}_{ff}^{-1}$$

- The inversion of the matrix is computationally intensive and needs to be performed for every frequency of analysis.
- An efficient in-place inversion routine is used to invert the flexibility matrix which is a full matrix in the direct method of analysis.
- For total number of  $i$  interacting nodes, the resultant impedance matrix of the order of  $3i \times 3i$  for three-dimensional problems.



# Global Impedances

- The ACS SASSI code computes also the equivalent global impedance functions for the surface foundations.
- The global impedance functions are determined through a rigid body transformation.

$$\mathbf{K}_{\theta, Y}(\omega) = \sum_i (\mathbf{X}_i - \mathbf{X}_C) \sum_j (\mathbf{X}_j - \mathbf{X}_C) \mathbf{k}_{i,j}(\omega)$$

- Frequency dependent damping ratios corresponding to the equivalent global impedances are computed by analogy with a viscously damped SDOF system.

For a degree of freedom  $m$ ,  $m = x, y, z, xx, yy, zz$ , the damping ratio is:

$$\xi_m(\omega) = \frac{\text{Imag}[\mathbf{K}_m(\omega)]}{2 \text{Real}[\mathbf{K}_m(\omega = 0)]}$$

# Global Impedances for A Circular Rigid Disk

## Soil Layering

### SOIL LAYER DATA

N	H	W	VS	VP	DS	DP
1	0.1000E+02	0.1300E+00	0.9800E+03	0.2500E+04	0.1400E-01	0.1400E-01
2	0.1000E+02	0.1300E+00	0.9267E+03	0.2500E+04	0.2700E-01	0.2700E-01
3	0.1000E+02	0.1300E+00	0.8699E+03	0.2500E+04	0.3800E-01	0.3800E-01
4	0.1000E+02	0.1300E+00	0.8222E+03	0.2500E+04	0.4700E-01	0.4700E-01
H		0.1300E+00	0.1000E+04	0.2500E+04	0.5000E-01	0.5000E-01

### IMPEDANCE ANALYSIS RESULTS:


## Global Impedances

	DYN. STIFF.	VISC. DAMP.	DAMP. RATIO
FREQUENCY =		.05	
X	0.12333E+07	0.29910E+06	.04
Y	0.12333E+07	0.29910E+06	.04
Z	0.17374E+07	0.57989E+06	.05
XX	0.47310E+10	0.10835E+10	.04
YY	0.47310E+10	0.10835E+10	.04
ZZ	0.64420E+10	0.97004E+09	.02
FREQUENCY =		.98	
X	0.12229E+07	58515.	.15
Y	0.12229E+07	58515.	.15
Z	0.16677E+07	0.10748E+06	.19
XX	0.44906E+10	0.63635E+08	.04
YY	0.44906E+10	0.63635E+08	.04
ZZ	0.62360E+10	0.58461E+08	.03
FREQUENCY =		1.95	
X	0.11923E+07	51694.	.26
Y	0.11923E+07	51694.	.26
Z	0.15560E+07	96036.	.34
XX	0.40767E+10	0.55045E+08	.07
YY	0.40767E+10	0.55045E+08	.07
ZZ	0.57881E+10	0.54443E+08	.05
FREQUENCY =		2.93	
X	0.11419E+07	50326.	.38
Y	0.11419E+07	50326.	.38
Z	0.13731E+07	93976.	.50
XX	0.36258E+10	0.63139E+08	.12
YY	0.36258E+10	0.63139E+08	.12
ZZ	0.52989E+10	0.67180E+08	.10
FREQUENCY =		4.35	
X	0.10439E+07	50586.	.56
Y	0.10439E+07	50586.	.56
Z	0.98731E+06	96869.	.76
XX	0.29810E+10	0.75676E+08	.22
YY	0.29810E+10	0.75676E+08	.22
ZZ	0.46914E+10	0.85966E+08	.18
FREQUENCY =		4.88	
X	0.99937E+06	51050.	.63
Y	0.99937E+06	51050.	.63
Z	0.80895E+06	99279.	.88
XX	0.27330E+10	0.79879E+08	.26
YY	0.27330E+10	0.79879E+08	.26
ZZ	0.45010E+10	0.92041E+08	.22

# ACS SASSI SSI Modules:

1. **EQUAKE** – Generates Control Motion
2. **SOIL** – Compute Equivalent Soil Properties and Free-Field Motions
3. **SITE** – Compute Site Layering Behavior Under Different Wave Types
4. **POINT** – Compute Soil Layering Flexibilities Under Point Loads
5. **HOUSE** – Defines the Structure and Near-Field Soil and Incoherence
6. **ANALYS** – Compute Impedances & Solves SSI Problem (ATF solution)
7. **MOTION** – Computes Accelerations, RS in Structure/Near-Soil
8. **RELDISP** - Computes Relative Displacements
9. **STRESS** – Computes Stresses/Strains in Structure and Near-Soil
10. **COMBIN** – Combine ANALYS Solutions with Different Frequencies

# SSI Analysis Flowchart



# 1. Simulation of Input Control Motion (EQUAKE)

**EQUAKE Spectrum Compatible Accelerograms are assumed to be Independent or Correlated**

The screenshot shows the 'Analysis Options' dialog box for the EQUAKE software. The 'EQUAKE' tab is selected. The 'Spectrum Files' section includes fields for 'Spectrum Number' (1), 'Spectrum Input File' (D:\ASSI\NEWMHX.RSI), 'Spectrum Output File' (D:\ASSI\NEWMHX.RSO), and 'Acceleration Output File' (D:\ASSI\NEWMHX.ACC). The 'Optional Spectrum Files' section has an unchecked 'Input Acceleration' checkbox and an 'Acceleration Input File' field (C:\ASSI\ACCNSREC.ACC). The 'Number of Frequencies' is 19, 'Initial Random Number' is 19343, 'Damping Value' is 0.05, 'Time Step' is 0.005, and 'Total Duration' is 15. The 'Correlation' table is shown below:

No	Time	Corr.
1		
2	1	
3	3	
4	5	
5	6	

The 'Spectra Title' is 'Newmark GRS Horizontal'. The 'Correlated' checkbox is unchecked. The 'OK', 'Cancel', and 'Help' buttons are at the bottom.

**Is based on Wiener-Levy Algorithm...**




**Uses phasing from real records**

**Includes non-stationary correlation between X and Y components**

**Spectrum File - NEWMHX.RSO'**



**Time History File - m13r.acc**

# RG 1.60 Spectrum Compatible Accelerograms Using Random Phasing





US NRC SRP 3.7.1 Target PSD Requirement


# RG 1.60 Spectrum Compatible Accelerograms Using Recorded Phasing



## US NRC SRP 3.7.1 Target PSD Requirement



# Spectrum Compatible Accelerograms with Nonstationary Correlation





# 2. Nonlinear Site Response Analysis (SOIL)

Analysis Options

EQUAKE **SOIL** | SITE | POINT | HOUSE | FORCE | ANALYS | MOTION | STRESS | RELDISP | AFWRITE

Input Motion  
 Nr. of Fourier Components: 4096  
 Time Step of Input Motion: 0.005  
 Number of Values: 3000  
 Multiplication Factor: 0  
 Max. Value for Time History Gravity Accel. (ft/s<sup>2</sup> or m/s<sup>2</sup>) (used for free-fied analysis): 0.1  
 Gravity Accel. (ft/s<sup>2</sup> or m/s<sup>2</sup>): 32.2  
 Number of Header Lines: 0  
 Cutoff Frequency (Hz): 0  
 Control Point Layer: 1  
 File: D:\ssi\NEWMHX.ACC  
 Assign as Outcrop Motion

Soil Profile  
 Layer Number: 1  
 Property Number: 2  
 Dynamic Soil Property: Clay

Stresses & Strains  
 Compute Stresses  
 Save Stress Time History  
 Compute Strains  
 Save Strain Time History

Accelerations  
 No Computation  
 Compute Maximum  
 Compute Maximum & Time History  
 Outcropping

Response Spectrum  
 Save Response Spectrum  
 Outcropping

Iteration Parameters  
 Save Strain-Compatible Soil Properties  
 Number of Iterations: 8  
 Equiv. Uniform / Max Strain: 0.6

Damping Ratios: 0.02, 0.05

Dynamic Soil Property - Sand020

Dynamic Soil Property - Clay

SASSI Soil Layer View <2>

Layer	Thickness	Unit Weight	P-Wave Velocity	S-Wave Velocity	P-Wave Damping Ratio	S-Wave Damping Ratio	
1							
2							
3							
4	1	10	0.13	4000	2000	0.05	0.05
5	2	10	0.13	4000	2000	0.05	0.05
6	3	10	0.13	4000	2000	0.05	0.05
7	4	10	0.13	4000	2000	0.05	0.05
8	5	10	0.13	4000	2000	0.05	0.05
9	6	10	0.13	4000	2000	0.05	0.05
10	7	10	0.13	2500	1000	0.05	0.05
	8	10	0.13	2500	1000	0.05	0.05
	9	10	0.13	2500	1000	0.05	0.05
	10	10	0.13	2500	1000	0.05	0.05
	Halfspace		0.13	2500	1000	0.05	0.05

Use international or British unit systems

**Equivalent Soil Properties and Motions are computed assuming Vertically Propagating S and P Waves**

Select Dynamic Soil Property


Clay  
Rock  
Sand

New Edit Delete OK Cancel Help

No	Strain	Mod.Red.	Strain	Damp
1	0.0001	1	0.0001	0.24
2	0.0003	1	0.0003	0.42
3	0.001	1	0.001	0.8
4	0.003	0.981	0.003	1.4
5	0.01	0.941	0.01	2.8

Title Clay - Seed & Sun 1989 / Idriss 1990

**Nonlinear soil material curve database;  
Shear modulus and damping ratio as  
functions of soil shear strain**



**User can add edit, delete,  
and included new curves**

# Computation of Equivalent Soil Properties

## Input Acceleration Time History

```

MAXIMUM ACCELERATION = .85600
AT TIME = 4.37 SEC
THE VALUES WILL BE MULTIPLIED BY A FACTOR = .350
TO GIVE NEW MAXIMUM ACCELERATION = .30000
MEAN SQUARE FREQUENCY = 6.87 C/SEC.
*** CONTROL MOTION LAYER ***
** MOTION OF LAYER NUMBER 1 OUTCROPPING

*** STRAIN COMPATIBLE SOIL PROPERTIES ***
MAXIMUM NUMBER OF ITERATIONS = 8
STRAIN FACTOR IN TIME DOMAIN = .60
    
```

EARTHQUAKE - C:\ACS\_C\NEWMHX.ACC

**SOIL Module**  
**(based on SHAKE approach)**  
**Computes Equivalent Soil**  
**Properties Using**  
**Seed-Idriss Equivalent**  
**Linear Model**

## Initial Soil Layering Properties

```

*** SOIL PROFILE DESCRIPTION ***
NEW SOIL PROFILE NO. 1 IDENTIFICATION
NUMBER OF LAYERS 5 DEPTH TO BEDROCK 40.00

NO. TYPE THICKNESS DEPTH Tot. PRESS. MODULUS DAMPING UNIT WT. SHEAR VEL
      (ft) (ft) (ksf) (ksf) (kcf) (fps)
1 1 10.00 5.00 .65 4037. .050 .130 1000.0
2 1 10.00 15.00 1.64 4037. .050 .130 1000.0
3 1 10.00 25.00 2.31 4037. .050 .130 1000.0
4 1 10.00 35.00 2.99 4037. .050 .130 1000.0
5 BASE 4037. .050 .130 1000.0

PERIOD = .16 FOR AVERAGE SHEAR VELOCITY = 1000.
    
```

## Final Soil Layering Properties

ITERATION NUMBER 8

VALUES IN TIME DOMAIN

NO	TYPE	DEPTH (FT)	UNIFRM. STRAIN	<--- NEW	DAMPING USED	ERROR	<--- NEW	SHEAR MODULUS USED	ERROR	G/Go RATIO
1	1	5.0	.00296	.014	.014	.0	3877.2	3877.2	.0	.960
2	1	15.0	.00909	.027	.027	0.0	3466.9	3466.9	.0	.859
3	1	25.0	.01629	.038	.038	0.0	3055.3	3055.3	0.0	.757
4	1	35.0	.02485	.047	.047	0.0	2729.1	2729.2	0.0	.676

PERIOD = .18 FOR AVERAGE SHEAR VELOCITY = 900.

# Selection of Seismic Wave Environment (SITE)

The screenshot shows the 'Analysis Options' dialog box with the 'SITE' tab selected. The 'Non-Linear Soil' option is chosen under 'Operation Mode'. Under 'Mode 2', 'R-, SV-, and P-Waves' is selected. The 'SASSI Soil Layer View <5>' inset shows a table of soil layers with properties like thickness, unit weight, and wave velocities.

Layer	Thickness	Unit Weight	P-Wave Velocity	S-Wave Velocity	P-Wave Damping Ratio	S-Wave Damping Ratio
1						
2						
3	10	0.13	2500	1000	0.05	0.05
4	10	0.13	2500	1000	0.05	0.05
Halfspace		0.13	2500	1000	0.05	0.05

**SITE Module  
Compute Site Response  
Assuming A Selected  
Seismic Environment  
Including SV, P and R- or  
SH and L- wave  
Combination**

# Input for Computing Soil Flexibility Matrix (POINT)

Analysis Options

EQUAKE | SOIL | SITE | POINT | HOUSE | FORCE | ANALYS | MOTION | STRESS | RELDISP | AFWRITE

Operation Mode

Solution  Data Check

Number of Embedment Soil Layers: 0

Point Load Central Zone Radius: 13.8

OK Cancel Help

**POINT Module  
Compute Soil Layering  
Flexibility Matrix**

**Radius for Transmitting Boundary  
for point load at soil layer interface.  
It depends on interaction node mesh.**



# ACS SASSI Plane-Wave Incoherency Models

6 plane-wave incoherency models incorporated in the code:

HOUSE Input:

- 1) For Luco-Wong model, 1986 (theoretical, but unvalidated model)
- 2) For 1993 Abrahamson model for all sites and surface foundations
- 3) For 2005 Abrahamson model for all sites and surface foundations
- 4) For 2006 Abrahamson model for all sites and embedded foundations
- 5) For 2007 Abrahamson model for hard-rock sites and all foundations (NRC)
- 6) For 2007 Abrahamson model for soil sites and surface foundations

NOTE:

It should be noted that at this time only the 2007 Abrahamson for hard-rock site conditions is permitted by US NRC.

# Incoherent SSI Using Stochastic Simulation

The screenshot shows the 'Analysis Options' dialog box with the following settings:

- Operation Mode:**  Solution,  Data Check
- Dimension of Analysis:**  1D,  2D,  3D
- Flexible Volume Method:**
  - Flexible Volume:  Direct,  Skin
  - Flexible Interface:  Direct
- Acceleration of Gravity:** 32.2
- Ground Elevation:** -10
- Wave Passage:**
  - Use Wave Passage
  - Apparent Velocity for Line D: 1e+008
  - Angle of Line D with X Axis: 0
  - Unlagged Coherency Model: 3
- Motion Incoherency Simulation:**
  - Deterministic (Median) Incoherency Input
  - Stochastically Simulated Incoherency Input
- Soil Motion:**
  - Coherent,  Incoherent
  - Coherence Parameter X Dir.: 0.1
  - Coherence Parameter Y Dir.: 0.1
  - Coherence Parameter Z Dir.: 0.2
  - Mean Soil Wave Velocity: 1000
  - Number of Embed. Layers: 0
  - Time Step of Sismic Motion: 0.005
  - Nr. of Fourier Components: 4096
  - Frequency Set Number: 1
  - Number of Incoh. Modes: 0
  - Print Coherence Matrix
- Multiple Excitation:**
  - Use Multiple Excitation
  - Input Motion Number: 1
  - First Foundation Node: 1
  - Last Foundation Node: 69
  - X Coord. of Control Point: 0
  - Y Coord. of Control Point: 0
  - Z Coord. of Control Point: 0
  - Spectral Amplification Ratios: 1,1,1,1,1,1,1,1,1,1,1,1,1,1,1,1
  - Horizontal Seed Number: 63673
  - Vertical Seed Number: 28783
  - Random Phase (degrees): 180

Nonlinear SSI:

Stochastic approach for incoherent SSI. Use different SEED numbers for different simulations. Random phase is always 180.

Buttons: OK, Cancel, Help



# Near-Field Soil Input for Nonlinear SSI

By clicking the “Nonlinear SSI” Input Data in HOUSE a text file is opened for editing.

This file has extension .pin and needs to input in a free-format:

1st line: Number of nonlinear soil element groups, effective strain factor, number of soil material curves defined in SOIL (soil constitutive model);

2nd line: Number of the nonlinear soil element group, number of materials (could be equal with the number of layers or not) in the group and number of solid elements in the group

3rd line and after define a loop over the number of soil materials, with each line including: The initial shear modulus reduction factor (1.00 indicates same shear modulus as in free-field), the initial damping ratio factor (1.00 indicates the same damping as in free-field) and the soil material curve order number.



The block of lines after 1st line, needs to be input for all nonlinear soil element groups.

# Near-Field Soil Input for Nonlinear SSI (cont.)


Example with a single group of nonlinear soil elements, an effective strain factor of 0.60 and 2 soil material curves.

The order number of the nonlinear soil group is 2, the number of soil materials in the group is 5, and total number of elements in the group is 180.




For each the 5 soil material lines, we input 1.0 for the scale factor of G, 1.0 for the scale factor of D, and 1 for material curve (curve number are defined in SOIL).



# Performing Seismic SSI Analysis (ANALYS)



# Transfer Function Interpolation Technique



(after Tajirian, 1983)

# Transfer Function Interpolation Technique

- The frequency interpolation technique used to interpolate the response for frequencies in between the calculated and to obtain the response for all FFT frequencies is based on the frequency response function of a two-degree-of-freedom system.
- The total response of a two-degree-of-freedom system subjected to harmonic base excitation for each degree-of-freedom has the following general form

$$U^i(\omega) = \frac{C_1^i \omega^4 + C_2^i \omega^2 + C_3^i}{\omega^4 + C_4^i \omega^2 + C_5^i}$$

To compute the complex coefficients a five equation system needs to be solved

$$\begin{bmatrix} \omega_1^4 & \omega_1^2 & 1 & -\omega_1^2 U_1 & U_1 \\ \omega_2^4 & \omega_2^2 & 1 & -\omega_2^2 U_2 & U_2 \\ \omega_3^4 & \omega_3^2 & 1 & -\omega_3^2 U_3 & U_3 \\ \omega_4^4 & \omega_4^2 & 1 & -\omega_4^2 U_4 & U_4 \\ \omega_5^4 & \omega_5^2 & 1 & -\omega_5^2 U_5 & U_5 \end{bmatrix} \begin{bmatrix} C_1 \\ C_2 \\ C_3 \\ C_4 \\ C_5 \end{bmatrix} = \begin{bmatrix} \omega_1^4 U_1 \\ \omega_2^4 U_2 \\ \omega_3^4 U_3 \\ \omega_4^4 U_4 \\ \omega_5^4 U_5 \end{bmatrix}$$


Note:

Based on our experience that the two-degree-of-freedom-system interpolation technique may sometimes introduce some spurious spectral peaks and valleys. Thus, it is recommended when significant spectral peaks are identified between the frequency solution points to add new frequency points in that range.


# Criteria for Selecting Frequency Solution Points

- Depend on the number of peaks in the transfer function at the specific response location and how close these peaks are located relative to each other.
- The frequencies of analysis can be selected by recognizing that the SSI effects usually shift the frequencies to the lower frequency range and tend to flatten the sharp peaks or sometimes even eliminate the fixed-base response peaks.
- Most of the practical problems are sufficient to solve SSI solution for a limited number of frequencies; about 40-50 frequencies for stick SSI models and about 50-200 frequencies for 3D SSI models. A larger number of frequencies needed for rock sites than soil sites.
- If no information on natural frequencies of the system are is available, it is necessary to selected adequate number of frequencies with an uniform increment throughout the frequency range of interest. Then, after revising the results, more frequencies are added to reconstruct the missing spectral peaks.

ATF at Node 659 Y-Y





## Node 118 X-direction for Y-input






# ATF Interpolation Error Smoothing Results; No Smoothing vs. Smoothing For Interpolated ATF. Need to Correlate RS and ATF Results



“Spurious” ATF Peak Produced by the Interpolation Function

# Computing Nodal Accelerations (MOTION)







**SRSSTF.TXT**

**MOTION Module computes transfer functions, TFU and TFI files, motions, ACC files, and response spectra, RS at selected nodes, RS files.**


Includes 6 TF interpolation algorithms and explicit input parameters for error smoothing & phase adjustment.

**CONTRRS.TXT**


Saving Results, TFU, ACC and RS for Post-processing. Restart is used for generating frames for contour, deformed shape plots and animations





### Node 118 YZITF




# Including ATF Interpolation Error Smoothing. Results Using New Option 2. With Overlapping Moving Windows, $A=(A1+A2+A3+A4+A5)/5$



# ATF Interpolation Error Smoothing Results for EPRI AP1000 Stick Model. Comparisons for 224 SSI Frequencies vs. 2048 Fourier Frequencies




# Simulated Incoherent Interpolated ATF Using SASSI2000 (Option 0) and SASSI1982 (Option 1) Interpolation Schemes



# (Mean) Incoherent Interpolated ATF Using Different Interpolation Schemes


FLEXIBLE (SP10PA0, MODES=10)-- XINPUT -- ATF :







# (Mean) Incoherent Interpolated ATF Using Different Interpolation Schemes


FLEXIBLE (SP10PA0, MODES=10)-- ZINPUT -- ATF



# Effects of Phase Adjustment on Response Time History




5% Damped ARS at Node 145 (SCV Outrigger). Y-Direction, X-Shaking



X-input

No phase adjustment has no visible effect... Provides close values with CLASSI Inco or SRSS SASSI


5% Damped ARS at Node 145 (SCV Outrigger). Y-Direction, Z-Shaking




Z-input

No phase adjustment provides lower response...


# FRS Results With and Without ATF Phase Adjustment; With Single Accel Input and Multiple Accel Inputs



# FRS Results With and Without ATF Phase Adjustment; With Single Acc Input and Multiple Acc Inputs



# Generating Frame Files of TF, RS and TH Options



Generating all frame files of TF, RS and TH for all nodes

# Computing Relative Displacements (RELDISP)

The screenshot shows the 'Analysis Options' dialog box with the 'RELDISP' tab selected. The 'Reference Location and Direction' section has 'Complex TF File Name' set to '00000TR\_X.TFI'. In the 'Output Control' section, the checkbox 'Save Rel Disp Complex TF' is checked. The 'Acceleration Time History Data' section includes: 'Nr. of Fourier Components' (4096), 'Time Step of Control Motion' (0.005), 'Multiplication Factor' (0), 'Max. Value for Time History' (0.1), 'First Record' (1), and 'Last Record' (3000). The 'Title' is 'Newmark-Hall Spectrum' and the 'File' is 'D:\ssi\NEWMHX.ACC'. The 'Nodal Output Data' table is as follows:


Node Number	X	Y	Z
245	X	Y	Z
286	X		

In the 'Post Processing Option' section, the checkbox 'Save Relative Displacement in all nodes' is checked and circled in blue, and the checkbox 'Restart for Frame Generation' is unchecked. At the bottom are 'OK', 'Cancel', and 'Help' buttons.


**RELDISP Module computes transfer functions, TFD files, and motions, THD files for relative displacements.**

Saving Results, THD files, for Post-processing. Restart is used for generating frames for deformed shape plots and animations

### Group 3, Element 37 SYX




### Relative Displacement Node 570 - X Direction





# Computing Output Stresses (STRESS)



Save stress TFI and TFI files

**STRESS Module Computes Stresses/Strains Forces/Moments in Selected Structural or Near-Field Soil Elements**

Includes 6 TF interpolation algorithms and optional TF smoothing.


Saving Stress Results, THS for Post-processing. Restart is used for generating frames for contour plots and animations for stresses and soil pressures.

# STRESS TF INTERPOLATION ISSUES

Longitudinal View #1

Mean Soil - SXY - Group 33 - Subgroup 1

Spurious Interpolation Peak  
in SXY Amplitude TF  
(red spot) ELEMENT 215




Maximum SRSS In-Plane Shear Stress SXY f




# In-Plane Shear Stress in ELEMENT 215

(markers are for computed TF values and line is for interpolated TF values)



# New Stress Computation and Plotting Options




Improve stress accuracy. Compute and save stress TF using different interpolation schemes. Select stress TF interpolation option. See next slide for MOTION. Same options. Can verify results with PREP/TFU-TFI plots.


Post-Processing for stress and seismic pressure contour plots

Restart options are used after a selection of stress time frames is made (automatic in PREP/Batch)

# Save Inputs for SSI Analysis Run (AFWRITE)



# ACS SASSI Post Processing Capabilities



ACS-SASSI Prep

Model File Batch Plot Options Window View Help

Model Elements F5  
Nodes

Time History F6  
TFU-TFI Curves  
Soil Layers F7  
Spectrum F8  
Impedance  
Soil Property F9  
Bubble Plot  
Vector TF Plot  
Contour Plot  
Deformed Shape

Output  
LOAD MODEL NIS  
save  
SAVE MODEL NIS


Visualize only nodes  
NOTES:  
- Interaction nodes are plotted as red dots  
- You can select node numbering In Window Settings  
- You need to type command SAVE before plotting nodes

Compare computed and interpolated TF for acceleration and stresses

New useful plotting capabilities

NUM

# Checking SSI Interaction Nodes



# Transfer Function (TF), Response Spectra (RS) and Time History (TH) Text Files for Post-Processing

<b>RS</b>	Response spectra data files generated by the motion module	
	<b>Naming Scheme for TFU, TFI, TFD, ACC Files</b>	
	Characters 1-5	Node Number
	Characters 6-9	Translation (TR) or Rotational ( R ) degree of freedom
	Characters 10-11	Damping ratio number
<b>TFU</b>	Uninterpolated acceleration transfer functions written by the motion module and stress transfer functions	
<b>TFI</b>	Interpolated acceleration transfer functions written by the motion module and stress transfer functions written by the stress module	
<b>TFD</b>	Displacement transfer functions generated by the reldisp module	
<b>THD</b>	Displacement time history written by reldisp module	
<b>ACC</b>	Acceleration time history written by motion module	
	<b>Naming Scheme for Acceleration TFU, Acceleration TFI, TFD, THD, and ACC Files</b>	
	Characters 1-5	Node Number
	Characters 6-9	Translation (TR) or Rotational ( R ) degree of freedom
<b>TH</b>	Soil time history for layers	
	<b>Naming Scheme</b>	
	ACC***	Acceleration time history for soil layer *** i.e. ACC001.TH is the acceleration time history for soil layer 1
	SN***	Strain time history for soil layer *** i.e. SN001.TH is the strain time history for soil layer 2
	SS***	Stress time history for soil layer *** i.e. SS001.TH is the stress time history for soil layer 3
<b>THS</b>	Stress time history written by stress module	
	<b>Naming Scheme for THS, stress TFU, and Stress TFI</b>	
	etype_gnum_enum_comp	e.g. BEAMS_012_00001_FXI.THS
	etype =	element type
	gnum =	group number
	enum =	element number
	comp =	stress component
<b>Frames.txt</b>	Post processing frames for stress and motion	
<b>ELEMENT_CENTER_ABS_MAX_STRESSES.TXT</b>	List of maximum stresses for each element	
<b>STATIC_SOIL_PRESSESURES.TXT</b>	Defines additional soil pressure (geological pressure) to be included in soil pressure frames	
<b>SRSSTF.txt</b>	SRSS option in motion	



# Frame Files for Post-Processing

<b>RS Frames Naming Scheme</b>			
RS##_freq_filenum		e.g. \RS\RS01_000.10_00001	
	## =	Damping number	
	freq =	frequency	
	fnum =	Frame number	
<b>TFU Frames Naming Scheme</b>			
TFU_freq_filenum		e.g. \TFU\TFU_000.02_00001	
	freq =	frequency	
	fnum =	Frame number	
<b>ACC Frames Naming Scheme</b>			
ACC_time_filenum		e.g. \ACC\ACC_00.000_00001	
	time =	time	
	fnum =	Frame number	
<b>THD Frames Naming Scheme</b>			
THD_time_filenum		e.g. \THD\THD_00.000_00001	
	time =	time	
	fnum =	Frame number	
<b>Stress Frame Naming Scheme</b>			
stress_time_fnum_comp		e.g. \NTRESS\stress_00.000_00001_sig	
	time =	time	
	fnum =	Frame number	
	comp =	Stress Component	
	sig	Solids	Normal Stress
		Shells	Membrane Stress
	tau	Solids	Shear Stress
		Shells	Membrane Shear
	bdsig	Bending Stress (shell elements only)	
	bdtau	Bending Shear (shell elements only)	
<b>Soil Pressure Frame Naming Scheme</b>			
press_time_fnum_type		e.g. \SOILPRES\pres_00.000_00001_nod	
	time =	time	
	fnum =	Frame number	
	type =	Element Values or Nodal Values	
	ele	Element Values	
	nod	Nodal Values	

# Frame Files for Post-Processing (cont')

Maximum Value Frames			
<b>Stress</b>			
stress_ABS_MAX_comp		e.g. \NSTRESS\stress_ABS_MAX_sig	
	comp =	Stress Component	
	sig	Solids	Normal Stress
		Shells	Membrane Stress
	tau	Solids	Shear Stress
		Shells	Membrane Shear
	bdsig	Bending Stress (shell elements only)	
	bdtau	Bending Shear (shell elements only)	
<b>Soil Pressure</b>			
press_ABS_MAX_type		e.g. \SOILPRES\pres_ABS_MAX_nod	
	type =	Element Values or Nodal Values	
	ele	Element Values	
	nod	Nodal Values	

# Seismic SSI Response Structural Plotting Options

Bubble Plots – Static – Node Plots


Complex ATF Vector Plots – Animated – Node Plots

Contour Plots – Static or Animated – Element Plots with  
Hidden Lines – Time Sequence or Selected Time Frames

Deformed Shape – Animated – Element Plots with  
Hidden Lines – Time Sequence or Selected Time Frames

Show some real time examples.....

# Generating Frame Files of TF, RS and TH Options



Generating all frame files of TF, RS and TH for all nodes

# ACS MAIN Menu for Managing SSI Module Runs

The screenshot displays the ACS-SASSI Main application window. The 'Run' menu is open, showing a list of modules with their corresponding function keys. A callout box points to the 'Run All' option, stating: **RUN ALL Run Modules In A Selected Order**. Another callout box points to the 'RUN Run Modules One-by-One' option, stating: **RUN Run Modules One-by-One**. A third callout box points to the 'Number of Runs' field in the 'Run Modules' dialog box, stating: **Nonlinear SSI Iterations**. The 'Run Modules' dialog box is open, showing a list of modules with checkboxes. The 'HOUSE' and 'STRESS' modules are checked. The 'Number of Runs' field is set to 3. The 'FORCE' module is highlighted with a dashed border.


Module	Key
PREP	F2
EQUAKE	F3
SOIL	F4
LIQUEF	F5
SITE	F6
POINT	F7
HOUSE	F8
PINT	F9
FORCE	F10
ANALYS	Shift + F3
COMBIN	Shift +
MOTION	Shift +
STRESS	Shift +
RELDISP	

**Run Modules**


- EQUAKE
- SOIL
- LIQUEF
- SITE
- POINT
- HOUSE
- PINT
- FORCE
- ANALYS
- COMBIN
- MOTION
- STRESS

Number of Runs: 3

# ACS SASSI MAIN Input File Converters



# ANSYS (cdb) or SASSI2000 Input (.hou,.sit,.poi) Converter to ACS SASSI Input



# ANSYS CDB file to ACS SASSI PRE file Converter


The converter program will work with the following elements only

- BEAM4
- COMBIN14
- BEAM44
- SOLID45
- SHELL63
- MASS21

For BEAM4 and BEAM44 elements, the I, J, and K nodes must be defined.

For COMBIN14 elements, the spring direction must be set using KEYOPT(2) and KEYOPT(1) must be 0.

The material properties need to be changed after the model is converted. ANSYS uses density for materials, while ACS SASSI uses specific weight. The material data from the converter output file must be multiplied by gravity to get the correct material property for the SSI analysis.



FE Model




# Define SSI Module Names and Paths

The screenshot shows the ACS-SASSI Main software interface. The 'Directories' menu is open, and the 'Directories...' dialog box is displayed. The dialog box contains a list of modules and their corresponding paths. A callout box points to the 'HOUSE' and 'ANALYS' modules with the text 'Change HOUSE and ANALYS For Fast-Solver Code (Option FS)'.

Module	Path
Pre-Processor	;\SASSIV230A-07-29-10\diskAo\sassipreU.exe
File Converter	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
Soil Mesh Gen	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
EQUAKE Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
SOIL Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
LIQUEF Module	
SITE Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
POINT Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
HOUSE Module	;\IV230A-07-29-10\diskAo\HOUSEV230AI.exe
PINT Module	
FORCE Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
ANALYS Module	SIV230A-07-29-10\diskAo\ANALYSV230I.exe
COMBIN Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
MOTION Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
STRESS Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
BATCH Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29
RELDISP Module	D:\ssi\ACS_SASSI\disksX\reldispV230Ai.exe
LOADGEN Module	D:\ACSV2300ptionA\ACSSASSIV230A-07-29

Change HOUSE and ANALYS For Fast-Solver Code (Option FS)

# ACS SASSI PREP Used to Prepare Batch Runs



```

runbatch.bat x
1 @echo off
2
3 set mname=RBX
4
5 mkdir .\work
6 cd .\work
7
8 echo %mname% > site.inp
9 echo %mname%.sit >> site.inp
10 echo %mname%_site.out >> site.inp
11
12 echo %mname% > point.inp
13 echo %mname%.poi >> point.inp
14 echo %mname%_point.out >> point.inp
15
16 echo %mname% > house.inp
17 echo %mname%.hou >> house.inp
18 echo %mname%_house.out >> house.inp
19
20 echo %mname% > analys.inp
21 echo %mname%.anl >> analys.inp
22 echo %mname%_analys.out >> analys.inp
23
24 for %%j in (X Y Z) do (
25     if %%j NEQ Y (
26         copy ..\%mname%_%%j.sit %mname%.sit
27         C:\ACSV230\EXEB\Siteb.exe < site.inp
28
29         copy ..\%mname%_%%j.poi %mname%.poi
30         C:\ACSV230\EXEB\Point3b.exe < point.inp
31     )
32
33     if %%j EQU X (
34         copy ..\%mname%_%%j.hou %mname%.hou
35         C:\ACSV230\EXEB\Houseb.exe < house.inp
36     )
37
38     copy ..\%mname%_%%j.anl %mname%.anl
39     C:\ACSV230\EXEB\Analysb.exe < analys.inp
40     mkdir ..\%%jDIR
41     copy FILE8 ..\%%jDIR\FILE8_%%j
42     move *.out ..\%%jDIR
43 )
44
45 del *.* /Q
46 cd ..
47 rmdir .\work


```

```

runbatch.bat x Combine.bat x
1 @echo off
2
3 set ipath=..
4 set opath=.\Combine_FILE8
5
6 mkdir %opath%
7 cd %opath%
8
9 for %%i in (X Y Z) do (
10     copy %ipath%\Set1\%%iDIR\FILE8_%%i FILE81
11     for %%j in (2 3 4 5) do (
12
13         copy %ipath%\Set%%j\%%iDIR\FILE8_%%i FILE82
14         C:\ACSV230\EXEB\Combinb.exe
15         del FILE81
16         del FILE82
17
18         ren FILE8 FILE81
19
20     )
21     ren FILE81 FILE8_%%i
22 )
23

```

# Automatic Frequency and Stress Selections, plus FRS or TF Batch Plotting



# Batch Post-Processing Response Spectrum Curves

## *Compute Average of Several Spectral Curves (up to 15 curves per operation)*


This batch file is used to compute the average of three FRS or ATF inputs. Output file name is 00566TR\_X01.RS .

Batch text file:

Number of Curves

Average

```
1  
3 4 ./00566TR_X01.RS  
Blank Line  
./XDIR/00566TR_X01.RS  
./YDIR/00566TR_X01.RS  
./ZDIR/00566TR_X01.RS
```



## ***Enveloping and Broadening Several Spectral Curves (up to 15 curves per operation)***

This batch file is used to compute the broaden of six inputs. Output file name is 00565TR\_X01\_BRD.RS .

Batch text file:

Number of Curves

Enveloping & Broadening

```
1  
6 1 ./00565TR_X01_BRD.RS  
0 15  
./00565TR_X01_SLB.RS  
./00565TR_X01_SM.RS  
./00565TR_X01_SUB.RS  
./00565TR_X01_BLB.RS  
./00565TR_X01_BM.RS  
./00565TR_X01_BUB.RS
```

## ***Creating Images of Several Spectral Curves (up to 15 curves per operation)***

This batch file is used to plot three curves. Output image file name is 00566TR\_X01\_SUB.BMP. This image title is "Original Inputs".

Batch text file:

```
1
3 0 ./00566TR_X01_SUB.BMP
1 0 1 1 Original Inputs
./XDIR/00566TR_X01.RS
./YDIR/00566TR_X01.RS
./ZDIR/00566TR_X01.RS
```

Number of Curves

Capture Image

Title

Ticks and Log

## **Compute SRSS for Co-Directional Spectra (3 curves per operation)**

This batch file is used to compute SRSS of three inputs. Output file name is 00566TR\_X01\_SUB.RS.


Batch text file:

Number of Curves  
SRSS

1  
3 2 ./00566TR\_X01\_SUB.RS

Blank Line

./XDIR/00566TR\_X01.RS  
./YDIR/00566TR\_X01.RS  
./ZDIR/00566TR\_X01.RS





# Batch Processing of Time Histories

This Example Combines 3 time histories by addition and saves the result in New\_Timehist.th

Time History Batch Text

Number of Files

1

3 0 New\_Timehist.th

00001TR\_X.acc

00046TR\_X.acc

00052TR\_X.acc

Algebraic Addition

# Batch Automatic Selection of SSI Frequencies

## *Batch Frequency Selection Option*

The first number in the header line is the number of files to use to find additional frequencies.

Input File

```
5 95 30  
00778TR_X  
01057TR_X  
02098TR_X  
02190TR_X  
04970TR_X
```

The second number in the header is the tolerance on the difference between the TFI and TFU.

The third number in the header line is the percent below the max for which peaks are ignored .

After the header line, the files sets to be checked are listed without the file extension.

**See Excel file**

# Automatic Selection of Frames for Vector TF Plotting

## Vertical TF Frame Selection Option

Input File: \*.tfani

```
1 20 1  
C:\AP1000_STICK\XDIR\TFU  
TFU_000.02_00001  
TFU_000.17_00002  
TFU_000.34_00003  
TFU_000.49_00004  
TFU_000.59_00005  
TFU_000.68_00006  
TFU_000.78_00007  
TFU_000.88_00008  
TFU_001.00_00009  
TFU_001.10_00010  
TFU_001.20_00011  
TFU_001.29_00012  
TFU_001.42_00013  
TFU_001.49_00014  
TFU_001.59_00015  
TFU_001.68_00016  
TFU_001.78_00017  
TFU_001.88_00018  
TFU_002.00_00019  
TFU_002.10_00020
```

The first line is the number of files to create the frame: files from 1 to 20 by increments of 1

The second line is the directory of the 20 files.

20 files' name are listed.

# Automatic Selection of Frames for Deformed Shape Plotting of Response Spectra

## Frame RS Selection Option

Input File: \*.rsani

```
1 20 1
C:\AP1000_STICK\XDIR\RS
RS01_000.20_00001
RS01_000.21_00002
RS01_000.22_00003
RS01_000.23_00004
RS01_000.25_00005
RS01_000.26_00006
RS01_000.27_00007
RS01_000.29_00008
RS01_000.30_00009
RS01_000.32_00010
RS01_000.34_00011
RS01_000.36_00012
RS01_000.37_00013
RS01_000.39_00014
RS01_000.42_00015
RS01_000.44_00016
RS01_000.46_00017
RS01_000.49_00018
RS01_000.51_00019
RS01_000.54_00020
```

The first line is the number of files to create the frame: files from 1 to 20 by increments of 1

The second line is the directory of the 20 files.

20 files' name are listed.

# Automatic Selection of Frames for Deformed Shape Plotting of Time History

## Time History Frame Selection Option

Input File: \*.thani

```
1 20 1  
C:\AP1000_STICK\XDIR\ACC  
ACC_00.000_00001  
ACC_00.005_00002  
ACC_00.010_00003  
ACC_00.015_00004  
ACC_00.020_00005  
ACC_00.025_00006  
ACC_00.030_00007  
ACC_00.035_00008  
ACC_00.040_00009  
ACC_00.045_00010  
ACC_00.050_00011  
ACC_00.055_00012  
ACC_00.060_00013  
ACC_00.065_00014  
ACC_00.070_00015  
ACC_00.075_00016  
ACC_00.080_00017  
ACC_00.085_00018  
ACC_00.090_00019  
ACC_00.095_00020
```

The first line is the number of files to create the frame: files from 1 to 20 by increments of 1

The second line is the directory of the 20 files.

20 files' name are listed.

# Frame Plotting and Combination Examples For MOTION TFU, RS, ACC and RELDISP THD Files


## Frame\_Combine.txt

```
17602
3 1 .\Coherent\Combined\ACC\ACC_00.000_00001
.\Coherent\XDIR\ACC\ACC_00.000_00001
.\Coherent\YDIR\ACC\ACC_00.000_00001
.\Coherent\ZDIR\ACC\ACC_00.000_00001
3 1 .\Coherent\Combined\ACC\ACC_00.005_00002
.\Coherent\XDIR\ACC\ACC_00.005_00002
.\Coherent\YDIR\ACC\ACC_00.005_00002
.\Coherent\ZDIR\ACC\ACC_00.005_00002
3 1 .\Coherent\Combined\ACC\ACC_00.010_00003
.\Coherent\XDIR\ACC\ACC_00.010_00003
.\Coherent\YDIR\ACC\ACC_00.010_00003
.\Coherent\ZDIR\ACC\ACC_00.010_00003
3 1 .\Coherent\Combined\ACC\ACC_00.015_00004
.\Coherent\XDIR\ACC\ACC_00.015_00004
.\Coherent\YDIR\ACC\ACC_00.015_00004
.\Coherent\ZDIR\ACC\ACC_00.015_00004
3 1 .\Coherent\Combined\ACC\ACC_00.020_00005
.\Coherent\XDIR\ACC\ACC_00.020_00005
.\Coherent\YDIR\ACC\ACC_00.020_00005
.\Coherent\ZDIR\ACC\ACC_00.020_00005
```

## ACC\_Combined.thani

```
1 3000 1
.\Incoherent\Combined\ACC
ACC_00.000_00001
ACC_00.005_00002
ACC_00.010_00003
ACC_00.015_00004
ACC_00.020_00005
ACC_00.025_00006
ACC_00.030_00007
ACC_00.035_00008
ACC_00.040_00009
ACC_00.045_00010
ACC_00.050_00011
ACC_00.055_00012
ACC_00.060_00013
ACC_00.065_00014
ACC_00.070_00015
ACC_00.075_00016
ACC_00.080_00017
ACC_00.085_00018
ACC_00.090_00019
```

# Frame Selection for Contour Stress Plots for STRESS THS Files



## \*.contani

```
1 3000 1
.\Combined\
stress_00.000_00001_sig
stress_00.005_00002_sig
stress_00.010_00003_sig
stress_00.015_00004_sig
stress_00.020_00005_sig
stress_00.025_00006_sig
stress_00.030_00007_sig
stress_00.035_00008_sig
stress_00.040_00009_sig
stress_00.045_00010_sig
stress_00.050_00011_sig
stress_00.055_00012_sig
stress_00.060_00013_sig
stress_00.065_00014_sig
stress_00.070_00015_sig
stress_00.075_00016_sig
stress_00.080_00017_sig
stress_00.085_00018_sig
stress_00.090_00019_sig
```

# Batch Automatic Selection of Animation Frames for Contour Stress or Soil Pressure Plotting

## Batch Frame Selection Option Input File

```
20 ← 99  
SHELL_013_01374_SXX.THS  
SHELL_013_02276_SXX.THS  
SHELL_013_01337_SXX.THS  
SHELL_013_00576_SXX.THS  
SHELL_013_01645_SXX.THS  
SHELL_013_01891_SXX.THS  
SHELL_013_01920_SXX.THS  
SHELL_013_02674_SXX.THS  
SHELL_013_02185_SXX.THS  
SHELL_013_02092_SXX.THS  
SHELL_013_02458_SXX.THS  
SHELL_013_02811_SXX.THS  
SHELL_013_01430_SXX.THS  
SHELL_013_01785_SXX.THS  
SHELL_013_02249_SXX.THS  
SHELL_013_01273_SXX.THS  
SHELL_013_01488_SXX.THS  
SHELL_013_00487_SXX.THS  
SHELL_013_00372_SXX.THS  
SHELL_013_00621_SXX.THS
```

The first number in the header line is the number of files to use to find critical frames.


The second number in the header line is the percent of the node or element maximum used to identify the critical frames.

After the header line, the files sets to be checked are listed.



# Batch Processing for the Combination of Frames


This Example Combines Three frames by summation and SRSS and saves the results to Test\_Combin\_Frame.out AND Test\_Combin\_Frame2.out



# C. ACS SASSI Configuration and Use

- Modular Configuration
- Restart SSI Analysis Runs
- Building A Seismic SSI Analysis Model
- Hands-on Session ...

# ACS SASSI Modular Configuration



# Description of SSI Modules

## 1. EQUAKE

The EQUAKE module generates earthquake accelerograms that are compatible with given ground response spectra. The input file has extension .equ and it is created by the ACS SASSI PREP AFWRITE command. A time-varying correlation can be specified for the horizontal components.

The user can also use recorded accelerograms to control the phasing for the generated three-component accelerograms. The generated accelerograms are then be input in the site response analysis and SSI analysis through SOIL, MOTION and STRESS modules. For details on this, see also the V&V problem # 29 in the Verification Manual of the NQA version.

The NQA version EQUAKE in addition to the requested output files will produce a file with extension .psd that is a comparison of the calculated PSD versus target PSD for the RG 1.60 spectrum as defined in SRP 3.7.1.

## 2. SOIL

The SOIL module performs a nonlinear site response analysis using an equivalent linear model for soil hysteretic nonlinear behavior. The input file has extension .soi and it is created by the ACS SASSI PREP AFWRITE command.

The SOIL module is based on the SHAKE code methodology with some additional programming improvements done over years. The computed equivalent soil properties can be sequentially used in the SSI analysis. In addition to the output file, SOIL produces also other text files with extension .TH that are response time histories for plotting purposes. The TH files include time histories for accelerations (ACCxxx), soil layer strains (prefix SNxxx) and stresses (prefix Ssxxx). The xxx notations refers to free-field soil layer number (numbering is done from the ground surface to the depth).

SOIL also produces the text file File73 that contains the material soil curves that are used for the nonlinear SSI analysis by the STRESS module, and File88 with the iterated, equivalent linear or effective soil properties that are used by SITE if nonlinear SSI option is selected by the user.

## 4. Module SITE

The SITE module solves the site response problem. The input file has extension .sit and it is created by the ACS SASSI PREP AFWRITE command. The control point and wave composition of the control motion has to be defined in the input files . The information needed to compute the free-field displacement vector used is computed and saved on disk in File1. The program also stores information required for the transmitting boundary calculations in File2. The actual time history of the control motion is not required in this program module, but later in the MOTION module. The soil motion incoherency is introduced elsewhere, in the HOUSE module. In addition to the output and binary files File1 and File2, SITE also produces the text file IncohDirection file that contains a flag for the HOUSE module that is used when the incoherent SSI analysis option is selected.

## 5. Module POINT3 (or POINT2)

The POINT module consists of two subprograms, namely POINT2 and POINT3 for two- and three-dimensional problems, respectively. The input file has extension .poi and it is created by the ACS SASSI PREP AFWRITE command. The POINT module computes information required to form the frequency dependent flexibility matrix. The results are saved on File3. File2 created by program module SITE is required as input. Thus, the SITE module must be run before the POINT2 or POINT3 module.

## 6. Module HOUSE

The HOUSE module forms the mass and stiffness matrices of all the elements used in discretized model are determined and stored in File4. The input file has extension .hou and it is created by the ACS SASSI PREP AFWRITE command. The discretized model may include only the structure or also the irregular soil zone. The random field decomposition for incoherent motions is performed in this module. The HOUSE results for incoherent SSI are stored in File77 to be used by ANALYS. If the user wants to check the accuracy of the coherence kernel decomposition, HOUSE produces the text file File16. File 16 could be a very large size file. Therefore, we suggest select the coherence decomposition accuracy checking option only when it is very needed and justified.

HOUSE also produces the text file File78 that is a non-empty file only if nonlinear SSI analysis option is used. File78 is used by STRESS during the SSI nonlinear iterations.

The HOUSE module can be executed independent of SITE and POINT modules if the coherent SSI analysis option is used. If incoherent SSI analysis option is selected, then HOUSE has to be run after SITE.

HOUSE also incorporated an optimizer for node numbering. If the node renumbering option is selected a new HOUSE input text file with extension .hownew is saved in the working directory. This file contains the new optimized SSI model. This file will be used by ANALYS for computing the SSI solution for the optimized SSI model. This node numbering optimization can reduce significantly the SSI analysis run time especially for large-size SSI models with significant embedment that require very large run times of several thousand seconds per each SSI frequency.



## 9. Module ANALYS

The ANALYS module computes the problem solution for the required frequency steps. The input file has extension .anl and it is created by the ACS SASSI PREP AFWRITE command. Files1, File3 and File4 are always required as input files. For external load cases File9, and for incoherence analysis Files77 are also required as input.

ANALYS performs the following computational steps:

- Forms the flexibility matrix for the discretized model.
- Computes the impedance matrix for the discretized model.
- Determines the external load or seismic load vectors, including incoherency effects
- Solves the equation system for each frequency step, using triangularization and back-substitution algorithms and obtains transfer functions for each degree of freedom.

The solution output computed by the ANALYS module contains the complex transfer functions which depending on the option required are from the control motion to the final motions or from external loads to total displacements.

In either case, the SSI TF results are stored in File8 that is used by MOTION and STRESS for computing SSI responses. File5 and File6 are unformatted SSI solution database files with large sizes. These files are useful to be saved if repeated SSI reanalysis are needed; for example if the coherent SSI analysis is performed for a number of acceleration input time histories; or nonlinear SSI is used; or if the incoherent SSI analysis is done using the stochastic simulation or SRSS approach.

If the global, rigid body impedance analysis option is selected, ANALYS also produces File11 that is a quite large size file (this option selection is to be avoided if rigid body impedances are not needed by the user).

Interpolation of transfer functions in frequency domain and further output requirements are handled by the modules described below.

## 10. Module MOTION

The MOTION module reads the transfer functions from File8, and performs an efficient frequency domain interpolation using a complex domain scheme based on the 2 DOF complex transfer function model that has five parameters to be determined. The input file has extension .mot and it is created by the ACS SASSI PREP AFWRITE command. The interpolated transfer functions are then, used to compute the SSI response motions at a set of nodes selected by the user.

Acceleration, velocity, or displacement response spectra may be requested in different location points and degrees of freedom. The MOTION module requires only File8 as input. If baseline correction is used (this is a much more approximate solution to get relative displacements in a structure than using the RELDISP module), the nodal point motions are saved on File13 which a formatted file.

In addition to the output file that could be often very large size (if time histories are saved), MOTION produces specific text files for post-processing. These text files include the extension .TFU, .TFI, .ACC, .RS files that contain nodal SSI responses for the three translation DOF, respectively, the computed TF (TFU), interpolated TF (TFI), acceleration time histories (ACC) and the in-structure response spectra (RS) for selected damping values.

These text file names are xxxxxTR\_y.ext, where xxxxx is the node number, y is the DOF that can be X, Y or Z, and .ext is the extension that can be TFU, TFI or ACC. For response spectra files, the names are xxxxxTR\_yzz.RS, where zz is the order number of the damping ratio value (for example, 01 and 02 for two selected values of the damping ratio of 0.02 and 0.05). See Table 1 for more details on the SSI response text files.

If the MOTION post-processing restart option is used, then additional text files for post-processing are generated in the \TFU, \RS and \ACC subdirectories. These frame text files contain the SSI response values computed for all active nodal DOF at each frequency step or time step. These frame files are used by the ACS SASSI PREP module to create structural bubble plots, TF vector plots, contour plots, or deformed shape animations. See Table 2 for more details on frame text files.

## 11. Module RELDISP

The RELDISP module uses the acceleration complex TF computed by MOTION (TFI files) to compute analytically the relative displacements at different selected nodes. The input file has extension .rdi and it is created by the ACS SASSI PREP AFWRITE command. RELDISP produces an output file with the computed maximum nodal relative displacements. It also produces extension .TFD and .THD files that contain the nodal relative displacement complex TF and the relative displacement time history. Their names are similar to extension .TFU and .ACC files produced by MOTION. See Table 1 for more details on the SSI response text files.

If the RELDISP post-processing restart option is used, then additional text files for post-processing are generated in the \THD subdirectory. These frame text files contain the SSI response values computed for all active nodal DOF at each time step. These frame files are used by the ACS SASSI PREP module to create structural deformed shape animations. See Table 2 for more details on frame text files.

## 12. Module STRESS

The STRESS module computes requested stress, strain, and force time histories and peak values in the structural elements. The input file has extension .str and it is created by the ACS SASSI PREP AFWRITE command. The module STRESS requires File4 and File8 as inputs. Stress time histories are saved on File15, and the computed transfer functions of stresses or forces and moments are saved on File14. File15 and File 14 are text files. In addition to these text files, STRESS also produces File74, if the nonlinear SSI analysis option is employed. For nonlinear SSI, STRESS also uses File78 produced by HOUSE as an input.

In addition to the output file STRESS produces also some specific text files useful for post-processing. These text files include the extension .TFU, .TFI and .THS that contain structural element stress responses in each selected element, respectively, the computed TF (TFU), interpolated TF (TFI) and stress time histories (THS). These text file names have the format `etype_gnum_enum_comp` plus extension; for example, BEAMS\_003\_00045\_MXJ that contains the MX moment at node J for the BEAM element number 45 that belongs to Group 3. See Table 1 for more details on SSI response text files.

The STRESS module in addition to the above files also generates an important text file named `ELEMENT_CENTER_ABS_MAX_STRESSES.TXT` that contains the maximum element stress components (calculated by STRESS) for all the selected elements by the user.

If the STRESS post-processing restart option is used, then additional text files for post-processing are generated in the \NSTRESS subdirectory. These frame files are used by the ACS SASSI PREP module to create structural node stress contour plots, static (for a selected time or for maximum stress values) or animated. The STRESS post-processing handles only SOLID and SHELL elements for 3D SSI models. If the SSI model contains both SOLID and SHELL elements, the frames include only average node stresses for the membrane stresses. For the SHELL elements only, separate frames are generated for the average node bending stresses (the file extension include letters bd from bending). See Table 2 for more details on frame text files.

If the SSI model includes near-field soil elements that are adjacent to the foundation walls, then the soil pressure frames can be generated. The soil pressure frames are saved in \SOILPRES subdirectory. In addition to the seismic soil pressures frames at each time step, a single frame with maximum soil pressures is also generated. The user can also create total soil pressure frames including the static bearing pressures plus the computed seismic pressures. The static pressure text file is named STATIC\_SOIL\_PRESSES.TXT and is generated when the soil pressure frames are requested. When it is generated the first time by the STRESS restart analysis for soil pressure option, the static pressure file has only zero values

. Then, if the user inputs the non-zero static pressure values and runs again the STRESS post-processing restart for soil pressure option, these non-zero static pressures are added to the seismic pressures values using algebraic summation and the total soil pressures are saved in the soil pressure frames stored in the \SOILPRES subdirectory.

If the soil pressure restart option is used, then, other two text files are generated, namely pres\_max\_ele and pres\_max\_nod files. They contain the maximum element soil pressures (calculated by STRESS) and the average nodal soil pressures (approximate values to be used only for plotting purpose) in the SOLID elements that model the adjacent near field soil.

NOTE: It should be noted that the STRESS frame files contain average nodal stresses and average nodal pressures to be used only for plotting purposes. The element nodal stresses and soil pressures were computed directly from the SOLID element center stresses or pressures (normal stress to the solid element face). The element nodal stress was assumed to be equal to element center stress that introduce a certain level of approximation of the nodal stresses (no shape functions are used). In addition, the nodal averaging process could produce stresses and pressures could produce values that are difficult to interpret and use.



The accurate stress and soil pressure values to be used by the analyst for the SSI calculations and seismic design are the computed values in the element centers (that are provided in the STRESS outputs, or the text files called ELEMENT\_CENTER\_ABS\_MAX\_STRESSES.TXT and pres\_max\_ele), not the nodal average values. However, the average nodal stress and soil pressure add invaluable information for understanding the SSI model seismic behavior and for identifying the critical stress zones, or critical pressure areas on the foundation walls and mat.

For the nonlinear SSI analysis option, STRESS generates the File74 after each SSI iteration. File74 is then used by HOUSE for the next SSI iteration.

## 12. Module COMBIN

The COMBIN module combines results computed for different frequencies from two ANALYS runs. This module is useful when after the solution was obtained it is found that some additional frequencies are needed to be included. The COMBIN module requires as input two solution files of File8 type, renamed File 81 and File 82. The output file of this module is a new File8 obtained by combining the two old solution files.

# Batch SSI Analysis Runs

If the SSI runs are done in the batch mode under a DOS window, then, a batch file needs to be created. To run a SSI module in batch mode, the following DOS command is required:

```
SSI_module_name.exe < SSI_module_name.inp
```

where SSI\_module\_name could be SITE, or POINT or ANALYS. The SSI module executables are installed by default in the ACS\_C directory on the hard drive, and are also provided on the ACS SASSI installation CD-ROM in the Batch. Each input file with the SSI\_module\_name and the extension .inp contains only three input lines:

```
modelname  
modelname.ext_input  
modelname_SSI_module_name.out
```

where ext\_input is the extension provided by the ACS SASSI PREP AFWRITE command.

# Restart SSI Analyses

The restart analyses imply that large files (File 5 and File 6) were saved. The following changes of problem parameters need different levels for the restart analyses:

## 1. **Change in the Control Motion**

Suppose results are required for a different time history (or response spectrum) of the control motion. Then, as long as the nature of seismic environment, i.e., the type of wave field, is not changed, only the module MOTION has to be re-executed.

## 2. **Change in Seismic Environment**

Suppose that structure was originally analyzed for the effects of vertically propagated body waves and that results are required for the case of incident Rayleigh waves causing the same motion at the control point as in the free field. In this case only a part of the SITE module and ANALYS module have to be re-executed.

If the incoherency of seismic motion is changed, then the HOUSE module has to be re-executed also for creating a new File 77 for ANALYS input.

# Restart SSI Analyses (cont.)

## 3. **Change in Structure or Near-Field Soil**

If changes are made in the superstructure or in the motion incoherency characteristics, the HOUSE, ANALYS and MOTION modules have to be re-executed. Only File5 is needed for restart.

In general, we recommend the application of the FI-EVBN method that provides both numerical accurate and reasonable computational speed when compared with the reference FV method. The FI-EVBN method is several times faster than the FV method and only few times slower than the FI-FSIN method.

For the application of the FI-FSIN method for soil sites, we always recommend a preliminary sensitivity study to check it against the FV or FI-EVBN methods, especially for situations with foundation excavation in very soft soils (or backfill soils). The FI-FSIN could be sometime numerically unstable in the higher frequency range depending on the surrounding soil stiffness and the excavation volume configuration. For stiffer soil sites or rock sites, the FI-FSIN method is expected to provide highly accurate results coincident with the FV and FI-EVBN method results.

It should be also noted that the FV method is typically more robust to excavation volume horizontal mesh size than the FI methods. The FI-FSIN is especially sensitive to horizontal mesh variation in excavation volume. FI-FSIN becomes unstable in higher frequency ranges much faster than FI-EVBN.

# **2010 ACS SASSI-ANSYS Integration for Refined Seismic Structural Stress Analysis and Soil Pressure Computations**

# ACS SASSI-ANSYS Interface for Seismic Soil-Structure Interaction Analysis of Nuclear/Critical Facility Structures

ACS SASSI-ANSYS Interface provides new SSI analysis capabilities through ANSYS:

For structural stress analysis:

- *ANSYS Equivalent-Static Seismic SSI Analysis* Using Refined Mesh FE Models
- *ANSYS Dynamic Seismic SSI Analysis* Using Nonlinear or More Refined FE Models (including refined mesh, element types including local nonlinearities, nonlinear materials, contact elements, etc.)


For soil pressure computation:

- *ANSYS Equivalent-Static Seismic Soil Pressure Computation* Including Soil-Foundation Separation Effects




# ACS SASSI Seismic SSI Analysis

Computing Structural Stress/Forces



Selected Critical Time Steps for Maximum Stresses To be Used for Equivalent Static Structural Analysis




## SSI Solution Time Frames As Equivalent Static Structural Loading at Critical Time Steps

EQS Forces + BC Springs

EQS Forces + BC Displacements

EQS Relative Displacements




# ACS SASSI – ANSYS Interface for Refined Seismic Stress Analysis




ANSYS Structural Model  
Automatically Converted From  
ACS SASSI Using PREP Module

ANSYS Refined Structural Model  
Using EREFINE command or  
ANSYS GUI (rank 1-6)




# ACS SASSI Seismic SSI Analysis

Computing Seismic Soil Pressures




Selected Critical Time Steps for Maximum Stresses To be Used for Equivalent Static Structural Analysis




## SSI Solution Time Frames As Equivalent Static Loading at Critical Time Steps


EQS Forces – Linear & Nonlinear




EQS Relative Displacements – Linear (Welded)



# ACS SASSI – ANSYS Interface for Seismic Soil Pressure Analysis




← ANSYS Soil FE Model  
Is Automatically Generated  
by SOILMESH Module



Embedment mesh is extended.  
User controls extension size and  
mesh density. Can use EREFINE.  
Contact surfaces automatically added  
By ACS SASSI SOILMESH module.




# New Structural Model Converter from ACS SASSI to ANSYS



ACS SASSI model to ANSYS model converter.  
- Excavation volume is deleted, floating nodes fixed  
- Interaction nodes are converted to fixed nodes

In progress

# ACS SASSI – ANSYS Interface for Refined Seismic Stress Analysis



The screenshot displays the ACS-SASSI Main software interface. The 'Run' menu is open, showing a list of analysis options. The options are:

Option	Shortcut
PREP	F2
EQUAKE	F3
SOIL	F4
LIQUEF	F5
SITE	F6
POINT	F7
HOUSE	F8
PINT	F9
FORCE	F10
ANALYS	Shift + F3
COMBIN	Shift + F4
MOTION	Shift + F5
STRESS	Shift + F6
RELDISP	
CONVERTERS	
ANSYS Eq. Static Load	
ANSYS Dynamic Load	
ANSYS Soil Mesh Generator	
BATCH	

On the right side of the interface, there is a list of modules with checkboxes:

- EQUAKE Module
- SOIL Module
- SITE Module
- POINT Module
- HOUSE Module
- FORCE Module
- ANALYS Module
- PINT Module
- COMBIN Module
- MOTION Module
- STRESS Module

A text box with arrows pointing to the 'ANSYS Eq. Static Load', 'ANSYS Dynamic Load', and 'ANSYS Soil Mesh Generator' options in the Run menu contains the following text:

**ANSYS Interface Seismic Analysis Options includes:**

- ANSYS Equivalent Static Seismic Structural Analysis
- ANSYS Dynamic Seismic Structural Analysis
- ANSYS Equivalent Static Seismic Soil Pressure Analysis

# New ACS SASSI Modules for ANSYS Interface – for Structure & Soil

The screenshot shows the ACS-SASSI Main application window with a 'Directories...' dialog box open. The dialog lists the following modules and their paths:

Module	Path
Pre-Processor	D:\ssi\ACS_SASSI\disk\X\sassipre.exe
File Converter	D:\ssi\ACS_SASSI\disk\X\translator.exe
Soil Mesh Gen	D:\ssi\ACS_SASSI\disk\X\SoilMesh.exe
EQUAKE Module	D:\ssi\ACS_SASSI\disk\X\equakev230i.exe
SOIL Module	D:\ssi\ACS_SASSI\disk\X\soilv230ir1.exe
LIQUEF Module	
SITE Module	D:\ssi\ACS_SASSI\disk\X\sitev230ir2.exe
POINT Module	D:\ssi\ACS_SASSI\disk\X\point3v230ir1.exe
HOUSE Module	D:\ssi\ACS_SASSI\disk\X\housev230i.exe
PINT Module	
FORCE Module	D:\ssi\ACS_SASSI\disk\X\forcev230i.exe
ANALYS Module	D:\ssi\ACS_SASSI\disk\X\analysv230i.exe
COMBIN Module	D:\ssi\ACS_SASSI\disk\X\combinv230i.exe
MOTION Module	D:\ssi\ACS_SASSI\disk\X\motionv230i.exe
STRESS Module	D:\ssi\ACS_SASSI\disk\X\stressv230i.exe
BATCH Module	
RELDISP Module	D:\ssi\ACS_SASSI\disk\X\reldispv230i.exe
LOADGEN Module	D:\ssi\ACS_SASSI\disk\X\Loadgen.exe

A callout box on the right side of the dialog lists the following new modules:

- ANSYS Load Gen (apply loading)
- ANSYS Soil Mesh (create soil model)
- ANSYS Rfull (extract nodal mass) - invisible

# Exporting Equivalent Static Loads to ANSYS

- From ACS SASSI-MAIN select “ANSYS Static Load” from the Run menu
- Fill in the appropriate boxes as described in the documentation
- ANSYS APDL input files are created containing the load data are created when the user clicks “OK”


The screenshot shows the 'ANSYS Static Load Converter' dialog box with the following fields and options:

- Data to Add From ACS SASSI to the ANSYS model:**
  - Displacements
  - Acceleration
  - Displacement and Acceleration
  - Displacement for Soil Module
- Use Multiple File Lists Inputs
- SASSI Model and Results Input:**
  - Path: F:\ssi\_results
  - HOUSE Module Input: solid\_box.hou
  - Displacement Results: THD\_04.105\_00822
  - Trans. Acceleration Results: (empty)
  - Rotational Disp.
  - Rotational Accel.
- ANSYS Model and Data Input:**
  - Path: F:\ansys\_files
  - Coarse: (empty)
  - Active Node List: box\_model.dof
- Mass Data for Inertial Load (Ignore for Displacement):**
  - Mass Type:  Lumped Mass,  Master Node Mass
  - Generate Mass Data
  - For Lumped Mass: Lumped Mass Data: (empty)
  - For Master Mass: Master Node Order, Master Node List, Master Node Mass: (empty)
- ANSYS Output File:** ADPL File: disp\_load.cmd



Buttons: OK, Cancel



# Exporting Equivalent Static Loads to ANSYS



Acceleration & Displacements BC  
(Uses ANSYS Refined Model Solution)  
- Accurate for Refined Stress Analysis



ANSYS Displacement BC  
(Uses ACS SASSI Model Solution)  
- Less Accurate for Refined Models



# Displacement Option – Use SSI Model Solution

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements    Acceleration    Displacement and Acceleration  
 Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path: F:\ssi\_results

HOUSE Module Input: solid\_box.hou <<

Displacement Results: THD\_04.105\_00822 << <<  Rotational Disp.

Trans. Acceleration Results: << <<  Rotational Accel.

ANSYS Model and Data Input

Path: F:\ansys\_files

Coarse: <<

Active Node List: box\_model.dof <<

Mass Data for Inertial Load (Ignore for Displacement)

Mass Type:  Lumped Mass    Master Node Mass    Generate Mass Data

For Lumped Mass: Lumped Mass Data: <<

For Master Mass: Master Node Order: <<  
Master Node List: <<  
Master Node Mass: <<

ANSYS Output File: ADPL File: disp\_load.cmd <<

OK   Cancel

# Acceleration Option – Select Nodal Mass Type

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration  
 Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path:

HOUSE Module Input:  <<

Displacement Results:  <<  <<  Rotational Disp.

Trans. Acceleration Results:  <<  <<  Rotational Accel.

ANSYS Model and Data Input

Path:  F:\ansys\_files

Coarse:  box\_ansys\_coarse <<

Active Node List:  <<

Mass Data for Intertial Load (Ignore for Displacement)

Mass Type  
 Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass  
Lumped Mass Data:  lumped\_mass.dat <<

For Master Mass  
Master Node Order:  <<  
Master Node List:  <<  
Master Node Mass:  <<

ANSYS Output File  
ADPL File:  get\_lumped\_mass.cmd <<

OK Cancel

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration  
 Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path:  F:\ssi\_results

HOUSE Module Input:  solid\_box.hou <<

Displacement Results:  <<  <<  Rotational Disp.

Trans. Acceleration Results:  <<  <<  Rotational Accel.

ANSYS Model and Data Input

Path:  F:\ansys\_files

Coarse:  <<

Active Node List:  box\_model.dof <<

Mass Data for Intertial Load (Ignore for Displacement)

Mass Type  
 Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass  
Lumped Mass Data:  <<

For Master Mass  
Master Node Order:  master\_def.lst <<  
Master Node List:  master\_nodes.lst <<  
Master Node Mass:  master\_mass.dat <<

ANSYS Output File  
ADPL File:  get\_master\_mass.cmd <<

OK Cancel

# Acceleration Option – With Nodal Lumped Masses

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration  
 Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path: F:\ssi\_results

HOUSE Module Input: solid\_box.hou

Displacement Results: [ ] [ ]  Rotational Disp.

Trans. Acceleration Results: ACC\_04.105\_00822 [ ] [ ]  Rotational Accel.

ANSYS Model and Data Input

Path: F:\ansys\_files

Coarse: [ ]

Active Node List: box\_model.dof

Mass Data for Inertial Load (Ignore for Displacement)

Mass Type:  Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass

Lumped Mass Data: lumped\_mass.dat

For Master Mass

Master Node Order: master\_def.lst

Master Node List: master\_nodes.lst

Master Node Mass: master\_mass.dat

ANSYS Output File

ADPL File: acc\_load\_822.cmd

OK Cancel

# Acceleration Option – With Nodal Master DOF Masses

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration  
 Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path F:\ssi\_results

HOUSE Module Input solid\_box.hou <<

Displacement Results << <<  Rotational Disp.

Trans. Acceleration Results ACC\_04.105\_00822 << <<  Rotational Accel.

ANSYS Model and Data Input

Path F:\ansys\_files

Coarse <<

Active Node List box\_model.dof <<

Mass Data for Inertial Load (Ignore for Displacement)

Mass Type  
 Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass  
Lumped Mass Data <<

For Master Mass  
Master Node Order master\_def.lst <<  
Master Node List master\_nodes.lst <<  
Master Node Mass master\_mass.dat <<

ANSYS Output File  
ADPL File acc\_master\_load\_822.cmd <<

OK Cancel

# Mixed Option – With Lumped Masses

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration  
 Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path F:\ssi\_results

HOUSE Module Input solid\_box.hou <<

Displacement Results disp\_list.txt << <<  Rotational Disp.

Trans. Acceleration Results acc\_frm\_list.txt << <<  Rotational Accel.

ANSYS Model and Data Input

Path F:\ansys\_files

Coarse <<

Active Node List box\_model.dof <<

Mass Data for Inertial Load (Ignore for Displacement)

Mass Type

Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass

Lumped Mass Data lumped\_mass.dat <<

For Master Mass

Master Node Order <<

Master Node List <<

Master Node Mass <<

ANSYS Output File

ADPL File mix\_lump\_apdl\_list.txt <<

OK Cancel

# Mixed Option – With Master DOF Masses

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration  Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path: F:\ssi\_results

HOUSE Module Input: solid\_box.hou

Displacement Results: disp\_list.txt

Trans. Acceleration Results: acc\_frm\_list.txt

Rotational Disp.  Rotational Accel.

ANSYS Model and Data Input

Path: F:\ansys\_files

Coarse:

Active Node List: box\_model.dof

Mass Data for Inertial Load (Ignore for Displacement)

Mass Type:  Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass

Lumped Mass Data:

For Master Mass

Master Node Order: master\_def.lst

Master Node List: master\_nodes.lst

Master Node Mass: master\_mass.dat

ANSYS Output File

ADPL File: mix\_master\_apdl\_list.txt

OK Cancel

# Example of Equivalent Static APDL File Created

```
forces.inp - Notepad
File Edit Format View Help
FINISH
/prep7
Node_Id=Node( 0.300000000E+01, 0.300000000E+01, 0.530000000E+02)
F,Node_Id,FX, 0.120690430E+03
F,Node_Id,FY, 0.179244520E+02
F,Node_Id,FZ, 0.259900690E+02
Node_Id=Node( 0.300000000E+01, 0.600000000E+01, 0.530000000E+02)
F,Node_Id,FX, 0.133931875E+03
F,Node_Id,FY, 0.197587250E+02
F,Node_Id,FZ, 0.250601330E+02
Node_Id=Node( 0.300000000E+01, 0.130000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.187532156E+03
F,Node_Id,FY, 0.221239760E+02
F,Node_Id,FZ, 0.247980250E+02
Node_Id=Node( 0.300000000E+01, 0.230000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.265551468E+03
F,Node_Id,FY, 0.163200870E+02
F,Node_Id,FZ, 0.259055440E+02
Node_Id=Node( 0.300000000E+01, 0.330000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.313659073E+03
F,Node_Id,FY, 0.795919600E+01
F,Node_Id,FZ, 0.262560410E+02
Node_Id=Node( 0.300000000E+01, 0.430000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.328311039E+03
F,Node_Id,FY, 0.000000000E+00
F,Node_Id,FZ, 0.258664210E+02
Node_Id=Node( 0.300000000E+01, 0.530000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.313659073E+03
F,Node_Id,FY, -0.795919600E+01
F,Node_Id,FZ, 0.262560410E+02
Node_Id=Node( 0.300000000E+01, 0.630000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.265551468E+03
F,Node_Id,FY, -0.163200870E+02
F,Node_Id,FZ, 0.259055440E+02
Node_Id=Node( 0.300000000E+01, 0.730000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.187532156E+03
F,Node_Id,FY, -0.221239760E+02
F,Node_Id,FZ, 0.247980250E+02
Node_Id=Node( 0.300000000E+01, 0.800000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.133931875E+03
F,Node_Id,FY, -0.197587250E+02
F,Node_Id,FZ, 0.250601330E+02
Node_Id=Node( 0.300000000E+01, 0.830000000E+02, 0.530000000E+02)
F,Node_Id,FX, 0.120690430E+03
F,Node_Id,FY, -0.179244520E+02
F,Node_Id,FZ, 0.259900690E+02
Node_Id=Node( 0.600000000E+01, 0.300000000E+01, 0.530000000E+02)
F,Node_Id,FX, 0.121983904E+03
F,Node_Id,FY, 0.360173100E+01
```



# Soil Model Option – Displacements at Interaction Nodes

ANSYS Static Load Converter

Data to Add From ACS SASSI to the ANSYS model

Displacements  Acceleration  Displacement and Acceleration

Displacement for Soil Module

Use Multiple File Lists Inputs

SASSI Model and Results Input

Path F:\ssi\_results

HOUSE Module Input solid\_box.hou <<

Displacement Results THD\_04.105\_00822 << <<  Rotational Disp.

Trans. Acceleration Results << <<  Rotational Accel.

ANSYS Model and Data Input

Path F:\ansys\_files

Coarse <<

Active Node List box\_model.dof <<

Mass Data for Inertial Load (Ignore for Displacement)

Mass Type

Lumped Mass  Master Node Mass  Generate Mass Data

For Lumped Mass

Lumped Mass Data <<

For Master Mass

Master Node Order <<



Master Node List <<

Master Node Mass <<

ANSYS Output File

ADPL File disp\_load\_4soil.cmd <<

OK Cancel





**Acceleration & Displacements BC**

1  
NODAL SOLUTION  
SUB =1  
TIME=1  
SEQV (AVG)  
DMX =.075844  
SMN =288597  
SMX =.139E+09

**SSI Model**

ANSYS

JUN 15 2010  
14:35:26





1  
NODAL SOLUTION  
SUB =1  
TIME=1  
SEQV (AVG)  
DMX =.075844  
SMN =182047  
SMX =.146E+09

**Refined Model**

ANSYS

JUN 15 2010  
14:41:16



# ANSYS Equivalent-Static vs. ACS SASSI


## SSI Analysis

**Surface Concrete Box  
SOLID Elements**


**Soil  $V_s=1000\text{fps}$**

Displacement and Acceleration Option  
SYY Component at t = 2.570 seconds


SXX



SYY



SZZ



# ANSYS Equivalent-Static vs. ACS SASSI


## SSI Analysis

**Deeply Embedded Concrete Box  
SOLID Elements**


**Soil  $V_s=1,000$  fps**

Displacement and Acceleration Option  
SYY Component at t = 4.870 seconds


SXX



SYY




SZZ



# ANSYS Dynamic Load Generation from ACS SASSI Frames

- From ACS SASSI-MAIN select “ANSYS Dynamic Load” from the Run menu
- Fill in the appropriate boxes as described in the documentation
- ANSYS APDL input files are created containing the load data are created when the user clicks “OK”




The screenshot shows the "ANSYS Dynamic Load Converter" dialog box. It is divided into several sections for input configuration:

- SASSI Model and Results Input:**
  - Path: F:\ssi\_results
  - HOUSE Module Input: solid\_box.hou (with a browse button <<)
  - Ground Acceleration File: NEWMHX.ACC (with a browse button <<)
- ANSYS Model and Data Input:**
  - Path: F:\ANSYS\_Files
  - Active Node List: box\_model.dof (with a browse button <<)
- Raleigh Damping Coeff.:**
  - Alpha: 0.45473e-3
  - Beta: 0.2154
- ANSYS Output File:**
  - ADPL File: dyn\_load.cmd (with a browse button <<)

At the bottom of the dialog are "OK" and "Cancel" buttons.

# ANSYS Dynamic Load APDL File Created



```
dynamic.inp - Notepad
File Edit Format View Help
FINISH
/Config,NRes, 6000
/SOLU
ANTYPE,TRANS
TRNOPT,FULL
ALPHAD, 0.45473e-3
BETAD, 0.2154
DELTIM 0.005
!
/INPUT,disp_gacc_load_00001
TIME, 0.0001
KBC,1
OUTRES,ALL, LAST
SOLVE
!
/INPUT,disp_gacc_load_00002
TIME, 0.0050
KBC,1
OUTRES,ALL, LAST
SOLVE
!
/INPUT,disp_gacc_load_00003
TIME, 0.0100
KBC,1
OUTRES,ALL, LAST
SOLVE
!
/INPUT,disp_gacc_load_00004
TIME, 0.0150
KBC,1
OUTRES,ALL, LAST
SOLVE
!
/INPUT,disp_gacc_load_00005
TIME, 0.0200
KBC,1
OUTRES,ALL, LAST
SOLVE
!
/INPUT,disp_gacc_load_00006
TIME, 0.0250
KBC,1
OUTRES,ALL, LAST
SOLVE
!
/INPUT,disp_gacc_load_00007
TIME, 0.0300
KBC,1
OUTRES,ALL, LAST
```



# ANSYS Dynamic vs. ACS SASSI

## SSI Analysis

**Surface Concrete Box**


**SOLID Elements**

**Soil  $V_s=1,000$  fps**


**Seismic Loading for ANSYS:**

**Ground Acceleration Histories and Relative  
Displacement Histories wrt Free-Field Surface Motion**


# ANSYS Dynamic vs. ACS SASSI – Surface SSI Model Above Ground Surface



# ANSYS Dynamic vs. ACS SASSI – for Surface SSI Model Below Ground Surface



# ANSYS Dynamic vs. ACS SASSI – for Surface SSI Model Below Ground Surface



# **ANSYS Dynamic vs. ACS SASSI**

## **SSI Analysis**


**Deeply Embedded Concrete Box**  
**SOLID Elements**  
**Soil  $V_s=1,000$  fps**

**Seismic Loading for ANSYS:**  
**Ground Acceleration Histories and Relative**  
**Displacement Histories wrt Free-Field Surface Option**  
**(No kinematic SSI included)**

# ANSYS Dynamic vs. ACS SASSI – Deeply Embedded SSI Model


## Above Ground Surface

Embedded Box Model




**NOTE:** In this example ANSYS results does not include kinematic SSI effects on acce

# ANSYS Dynamic vs. ACS SASSI – Deeply Embedded SSI Model Below Ground Surface



# ANSYS Dynamic vs. ACS SASSI – Deeply Embedded SSI Model Below Ground Surface






# New SOILMESH Module for Soil Pressure Computation

- Input .pre file with SSI model data
- Generates a soil FE model for soil pressure analysis using the “soilmesh” command
- Can export either structural or soil FE model to ANSYS APDL input file
- Computes seismic soil pressures produced using either
  - i) the foundation seismic forces pushing on surrounding soil, or
  - ii) the relative motion of the foundation wrt to the free-field soil motion.

Soil is assumed to be at rest. Soil stiffness is not frequency dependent. The new implementation produces “approximate” seismic soil pressures. Significant analysis improvement in comparison with the current practice.



```
SSI Soil Mesh Generator
File Help
DEFINE TRANSLATIONAL MASS 1263 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1264 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1265 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1266 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1267 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1268 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1269 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1270 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1271 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1272 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1273 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1276 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1277 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1278 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1279 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1280 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1281 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1282 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1283 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1284 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1285 fx:5 fy:5 fz:5
DEFINE TRANSLATIONAL MASS 1286 fx:5 fy:5 fz:5
House Model options set
INPUT FILE REACHED EOF, INPUT SWITCHED TO KEYBOARD
soilmesh,1,0.07,0.07,20,20,0,0,5
Soil Mesh created successfully.
actm,1
Active Model Switched to number : 1
ansys,box_soil
Wrote : box_soil.inp Successfully.

Command Entry
```


Soil Mesh command generates soil mesh

Ansys command generates ANSYS surrounding soil mesh


# Example of APDL file for Soil FE Model

```
box_soil.inp - Notepad
File Edit Format View Help
/!PREP7
! Element Type
ET,101,CONTA173
ET,102,TARGE170
ET,103,SOLID45
! Nodes
N,145,3,3,3
N,146,3,6,3
N,147,3,13,3
N,148,3,23,3
N,149,3,33,3
N,150,3,43,3
N,151,3,53,3
N,152,3,63,3
N,153,3,73,3
N,154,3,80,3
N,155,3,83,3
N,158,6,3,3
N,159,6,6,3
N,160,6,13,3
N,161,6,23,3
N,162,6,33,3
N,163,6,43,3
N,164,6,53,3
N,165,6,63,3
N,166,6,73,3
N,167,6,80,3
N,168,6,83,3
N,171,13,3,3
N,172,13,6,3
N,173,13,13,3
N,174,13,23,3
N,175,13,33,3
N,176,13,43,3
N,177,13,53,3
N,178,13,63,3
N,179,13,73,3
N,180,13,80,3
N,181,13,83,3
N,184,23,3,3
N,185,23,6,3
N,186,23,13,3
N,187,23,23,3
N,188,23,33,3
N,189,23,43,3
N,190,23,53,3
N,191,23,63,3
N,192,23,73,3
N,193,23,80,3
2013 COPYRIGHT OF GP TECHNOLOGIES - ACS SASSI V230 TRAINING NOTES 146
FOR "DAN GHIOGEL" RESEARCH CENTER, UTCS
```


# Example of Soil FE model Created Automatically by New SOILMESH Module for A Box Structural Model



# Equivalent-Static Stress Analysis for Structure-Soil System Model (Generated by SOILMESH)




# Computed Structural Displacements



# Linear Seismic Soil Pressure Analysis

## LINEAR (WELDED)

- This option provides for a basic soil pressure analysis assuming there is no separation possible between the structure and the soil
- Displacements from the interaction nodes of the structure are applied directly to the soil FE model. The structural FE model is not required for this case



# Nonlinear Seismic Soil Pressure Analysis

## NONLINEAR CONTACT


### (FOUNDATION SEPARATION)

- This option allows for the structure to separate from the soil using surface to surface contact elements in ANSYS


- Both the structural elements and the soil elements are required. Both APDL files written from SOILMESH must be loaded into ANSYS.

- Inertial Force should be applied to the structure.

- Contact and target surfaces are included in the soil FE model




# Nonlinear Seismic Soil Pressure Analysis







# ACS SASSI Seismic Soil Pressures for X-Input (Frame 903)





# ACS SASSI and ANSYS Element Stresses for X-Input (Frame 903)

Linear SSI Analysis

## SXX





## ACS SASSI





Welded FF Disp No Gravity 00826 - SXX Comp

## ANSYS Displacements Input



Welded Force No Gravity 00903 - SXX Comp


## ANSYS Forces Input



# ACS SASSI and ANSYS Element Stresses for $\lambda$ -Input (Frame 903)




Linear SSI Analysis

SYY




Welded Force No Gravity 00903 - SYY Comp

ACS SASSI






Welded FF Disp No Gravity 00903 - SYY Comp

ANSYS Displacements Input





ANSYS Forces Input





# ACS SASSI and ANSYS Element Stresses for X-Input (Frame 903)

Linear SSI Analysis

## SZZ





## ACS SASSI





Welded FF Disp No Gravity 00903 - SZZ Comp

## ANSYS Displacements Input



Welded Force No Gravity 00903 - SZZ Comp

## ANSYS Forces Input



# **2011 ACS SASSI ACS SASSI NQA V230 Fast-Solver Code (Option FS)**

# ACS SASSI NQA V230 Fast-Solver Code (Option FS)

The ACS SASSI “Fast-Solver Option” offers a much faster SSI analysis solution than the baseline code, especially for complex, larger-size FE models. The fast-solver code takes advantage of the newer Windows 64-bit multicore-processor PC architecture.

The ACS SASSI fast-solver code provides much faster solutions that are tens and hundreds of times faster than the standard SASSI software based on the skyline per block solution algorithm. The fast-solver code is much faster than the standard code, especially for larger-size SSI problems that include hundreds of thousands of equations, up to 100,000 nodes and 600,000 equations.

The larger the SSI model is, the more efficient the new fast-solver is in comparison with the standard SASSI solver based on the skyline per block algorithm. The required hard-drive storage by the new fast-solver version for the SSI initiation runs for large size models is only a small fraction of that required by the standard SASSI code versions.

SSI Analysis Runtime Comparison for Standard SASSI Algorithm vs. ACS SASSI Fast-Solver Algorithm Using A Windows 7 16 GB RAM PC with IC-7 3820 Processor

SSI Model Description	Total Number of Nodes	Number of Interaction Nodes	SSI Analysis Runtime/Frequency	
			Standard Algorithm	Fast-Solver Algorithm
TB Complex Surface Model	13152	1312	25 min	4 min
RB Complex Surface Model	18532	1389	47 min	5.5 min
RB Complex ** Embedded Model FV (7 layers)	27883	11200	Not Runnable, Too slow	408 min
RB Complex Embedded Model (4 layers) FI-EVBN	23715	3216	567 min	20 min
SSSI Standard Plant Surface Model	81120	7386	Non Runnable, Too slow	82 min
SSSI Standard Plant* (4 layers) Embedded Model FI-EVBN	71145	9648	Not Runnable, Too slow	244 min
NI Complex Embedded Surface Model	48082	3625	Not Runnable, Too slow	42 min
NI Complex Embedded Model (7 Layers) FI-EVBN	57246	7720	Not Runnable, Too slow	105 min
RB Complex Embedded Model (8 layers) FV*	35680	9310	Not Runnable, Too slow	135 min
SSSI RB-TB Surface Model	33690	2780	1210 min	25 min

\*these runs were done on 32 GB RAM PC with IC-7 3820 Processor

\*\*these runs were done on 64 GB RAM PC with IC-7 3820 Processor

# Automatic SSI Model Checking Tools

The ACS SASSI fast-solver code has some unique features for SSI model checking. The fast-solver code automatically checks the SSI solution based on the computed complex acceleration transfer functions (ATF).

*Zero-Frequency Checking:* For the 1st frequency (it should be frequency number equal to one), the fast-solver ANALYS module checks the ATF amplitudes for all the translation dofs in the principal direction. If the computed ATF amplitudes vary with more than 5% from unity, then a warning message is displayed and also printed in the ANALYS output. A list of the equations for which the ATF amplitude values deviate from 1.00 with more than 5% is provided in FILE66. Node number dofs could be identified using the node-equation mapping available in the HOUSE output. In these cases, the SSI model should be carefully revised by the user.

*All Frequency Checking:* For all selected SSI frequencies, the fast-solver ANALYS module codechecks the ATF amplitudes for abnormally large values. These could occur most likely due to poor FE modeling or SSI analysis input errors.



# Automatic Checking for Potential Unstable Solutions

If the ATF amplitudes for translation dofs indicate apparent spurious peaks/valleys, a message “potential unstable frequencies” will be displayed and printed in ANALYS output. A list of these potential unstable frequencies with apparent spurious solutions will be printed.

In addition to FILE8, there is a FILE80 that contains the complex ATF solution for the original SSI frequency set, and a FILE8C that contains the complex ATF solution for all the stable SSI frequencies. In FILE8C, the potentially unstable frequencies are not removed.

# Building SSI Models

## Demo Problems

# ACS SASSI NQA Verification & Validation

Verification Manual includes 37 Selected SSI Problems (more than 100 subproblems, 5,800 files, 480MB) to cover most of the ACS SASSI functionalities:

- Verify Results Against Other Codes: SHAKE91, ANSYS, etc.
- Verify Against Analytical Solutions
- Verify Against Experiments
- Verify by Engineering Body of Knowledge/Judgment
- Verify by a) Result Accuracy and b) Expected Behavior

*NQA Maintenance Service: Bugs and Error Reports, Periodic and Focused Memos with comments, Technical Investigation Reports (80 layers/2009, FV vs. FI methods/2010)*

# ACS SASSI Version 2.3.0 Problem Size Limitations

The most important ACS SASSI Version 2.3.0 *SSI problem size limitations*:

- Maximum number of SSI frequencies is 500 (1500 for MOTION, STRESS)
- Maximum number of soil layers is 125
- Maximum number of half-space layers is 20
- Maximum number of the time steps/Fourier frequency points is 16384
- Maximum number of damping ratios for response spectra computation is 5
- Maximum number of all SSI model nodes is limited by the hardware
- Maximum number of interaction nodes for global impedance analysis is 10,000
- Maximum of 5,000 interaction nodes per embedment level for incoherent SSI analysis.
- Maximum number of elements per group 500
- Maximum number of structural embedment node layers (sets with interaction nodes with different Z coordinates) for seismic motion incoherency analysis is 50

# Building A SSI Analysis Models

Step 1: Define Dynamic Inputs (Seismic Motion or Forces)

Step 2: Define Soil Layering

Step 3: Define Structure and Near Field Zone Using FE Modeling


Step 4: Define Seismic Motion Spatial Incoherency

Step 5: Select SSI Analysis Options (Assumptions, Methods, Parameters)


Step 6: Manage SSI Analysis Runs

Step 7: Post Processing for Extracting Results

## PARTICULAR ASPECT: CAVITY (SOLID) ELEMENTS





# Stick Models vs. FEA SSI Models



**Detailed 3D  
Structural  
FE Model**

Same Dynamic Properties  
→



**Stick Models.  
Labor Intensive  
Calibration  
Hidden Problem:  
STICKS COULD  
BE NUMERICALLY  
SENSITIVE**

# Specific SSI Model Building Requirements

The user manuals contain a large number of comments on various SSI modeling aspects.

Top-level recommendations of node and element numbering:

- Soil layering to be numbered from ground surface to baserock
- Excavation volume nodes to be numbered from baserock to ground surface
- Excavation volume layers to be numbered from ground surface to baserock
- Excavation volume elements to be numbered from ground surface to baserock

We also recommend always check the consistency of your soil layer or material element assignments for the soil excavation volume and the structural embedment part by revising the HOUSE output (modelname\_HOUSE.out).

For technical support please contact us by email at [dan.ghiocel@ghiocel-tech.com](mailto:dan.ghiocel@ghiocel-tech.com).

# **ACS SASSI Session for Describing the .Pre File Structure**



## Example of the .Pre File for A Embedded Rigid Cylinder

# .PRE File Structure

```
*****  
* THIS FILE WAS WRITTEN BY THE ACS SASSI PREPROCESSOR  
* To reload model type INP,<this file> in PREP  
*****
```

Comment lines starts by \*

```
TIT, EMBEDDED CYLINDER MODEL
```

Program title is defined by "TIT" command

```
* Nodes  
N,1,0,0,-70  
N,2,17.5,0,-70  
N,3,12.374,12.374,-70  
N,4,0,17.5,-70  
N,5,-12.374,12.374,-70  
N,6,-17.5,0,-70  
N,7,-12.374,-12.374,-70
```

Input Node Coordinates by "N" command:

# NGEN command

- **NGEN**, *ITIME*, *INC*, *NODE1*, *NODE2*, *NINC*, *DX*, *DY*, *DZ*  
Generates additional nodes from a pattern of nodes.

## *ITIME*, *INC*

Do this generation operation a total of *ITIME* times, incrementing all nodes in the given pattern by *INC* each time after the first. *ITIME* must be > 1 for generation to occur.

## *NODE1*, *NODE2*, *NINC*


Generate nodes from the pattern of nodes beginning with *NODE1* to *NODE2* in steps of *NINC*

## *DX*, *DY*, *DZ*


Node location increments

N, 1, 0.0, 0.0, 0.0



1 (x=0.0, y=0.0, z=0.0)



NGEN, 3, 5,1, 5, 1,0,1,0



Y



# .PRE File Structure

Input constrained displacement by "D" command:

\* Boundary Conditions

D,1,414,1,1,ROTX,ROTY,ROTZ

Input interaction nodes by "INT" command:

\* Interaction Nodes

INT,1,414,1,1,0

Input material properties by "M" command:

\* Material Table

M,1,1e+012,0.2,0,0,0,1,

# .PRE File Structure

## \* Soil Layer Table

```
L,1,14,0.12,1400,700,0.05,0.05  
L,2,10,0.12,1400,700,0.05,0.05
```

Input soil layer table by "D" command:

## \* Groups and Elements

```
GROUP,1,SOLID
```

Input element group information by "GROUP" command:

# .PRE File Structure

Input solid element by "E" command:

```
E,1,278,279,277,277,347,348,346,346  
E,2,279,280,277,277,348,349,346,346  
E,3,280,281,277,277,349,350,346,346  
E,4,281,282,277,277,350,351,346,346
```

```
EINT,1,440,1,1
```

EINT command for solid element

```
MSET,1,88,1,1
```

```
MSET,89,176,1,2
```

```
MSET,177,264,1,3
```

MSET command for solid element

# .PRE File Structure

```
GROUP,2,SOLID  
E,1,278,279,277,277,347,348,346,346  
E,2,279,280,277,277,348,349,346,346  
E,3,280,281,277,277,349,350,346,346  
E,4,281,282,277,277,350,351,346,346
```

Input solid element (Group #2) by "E" command:

```
ETYPE,1,440,1,1
```

"ETYPE" command for element group 2

```
EINT,1,440,1,2
```

"EINT" command for element group 2

```
MSET,1,440,1,2
```

MSET command for beam element



# EGEN Command

- **EGEN**, *ITIME*, *NINC*, *IEL1*, *IEL2*, *IEINC*

Generates elements from an existing pattern.

## *ITIME*, *NINC*

Do this generation operation a total of *ITIMEs*, incrementing all nodes in the given pattern by *NINC* each time after the first.


## *IEL1*, *IEL2*, *IEINC*

Generate elements from selected pattern beginning with *IEL1* to *IEL2* in steps of *IEINC*

## *MINC*


Increment material number of all elements in the given pattern by *MINC* each time after the first.

E,1,1,2,42,41,11,12,52,51




Element #1

EGEN,3,1,1,1,1



E #1-4  
(old 1) (new 2-4)

EGEN,2,10,1,4,1



E #1-12  
(old 1-4, new 5-12)

# .PRE File Structure

EQTIT,

“EQTIT” command

RSIN,1,  
RSIN,2,  
RSIN,3,

“RSIN” command

RSOUT,1,  
RSOUT,2,  
RSOUT,3,

“ROUT” command

ACCIN,1,  
ACCIN,2,  
ACCIN,3,

“ACCIN” command

# .PRE File Structure

THFILE

“THFIL” command

STRESS,0,1,1,1

“STRESS” command

\* Frequencies

FREQ,1,1,10,20,30,40,50,60,80,100,120

FREQ,2,1,10

FREQ,3,1,1,10,20,30,40,50

“FREQ” command

**Hands-on Session follows....**